



# WS4 TT Series Printers

## Technical Manual

WS408TT / WS412TT



# Contents

Preface .....	1
Who should read this manual .....	1
Related Documents.....	1
1 Understand Your Printer .....	2
1.1 Perspective View.....	2
1.2 Back View .....	3
1.3 Interior View I.....	4
1.4 Interior View II.....	5
1.5 Printer Button and Lights .....	6
1.5.1 Feed Button.....	6
1.5.2 Status Lights.....	6
2 Accessories Installation.....	8
2.1 Cutter.....	8
2.2 Dispenser.....	13
2.3 Wireless LAN Module.....	18
2.4 Bluetooth Module.....	21
2.5 External Unwinder .....	23
2.6 Paper Support Roller .....	25
3 System Mode.....	26
3.1 Media Sensor Calibration .....	27
3.2 Reset Your Printer .....	28
3.3 Self-Test and Dump Mode.....	29
3.3.1 Self-Test.....	29
3.3.2 Dump Mode.....	47
4 SATO WS4 Printer Utility .....	48
4.1 Install SATO WS4 Printer Utility .....	48
4.2 Work with SATO WS4 Printer Utility.....	51
4.2.1 Menu Bar .....	51
4.2.2 Toolbar .....	53
4.2.3 Navigation Pane .....	57
5 Update Firmware.....	90
5.1 Update Firmware in SATO WS4 Printer Utility .....	90
5.1.1 Update via the USB or COM Port.....	90
5.1.2 Update via the LAN Port.....	95
5.2 Update Firmware via the USB Host.....	100
5.3 Update Firmware in Atmel Mode .....	101

6	Troubleshooting.....	105
6.1	Cutter and Dispenser Issues .....	105
6.2	Internal Errors.....	106
7	Network .....	108
7.1	Network Architecture .....	108
7.2	Ethernet Status Indicators .....	110
8	Specifications.....	111
8.1	Printer .....	111
8.2	Media and Ribbon.....	113
8.3	Bar Code .....	115
8.4	Wireless LAN.....	117
8.5	Bluetooth.....	119
8.6	Ethernet.....	120
8.7	Electrical and Operating Environment.....	120
8.8	Physical Dimension .....	120
8.9	Interfaces.....	121
8.9.1	USB .....	121
8.9.2	Ethernet.....	122
8.9.3	RS-232C.....	123
9	Technical Drawings .....	125
9.1	Main board Diagram.....	125
9.2	System Diagram .....	127
9.3	Wiring Diagram .....	129
Appendix A:	DIP Switch.....	130

# Preface

This manual describes technical information about WS TT printers, including installation guides, operating guides, printer setting tool help, network architecture overview and technical drawings. It doesn't contain programming examples. For more information about printer programming, see related documents.

## Who should read this manual

This manual is intended for dealers, technicians and users who need to install and manage the hardware, firmware and network of WS TT printers.


## Related Documents

- WS TT Series Owner's Manual

# 1 Understand Your Printer


This chapter provides an overview of the printer.

## 1.1 Perspective View




# 1.2 Back View

## Standard Model




## Optional Interfaces


### LAN Model



## 1.3 Interior View I



## 1.4 Interior View II



## 1.5 Printer Button and Lights

This section describes the functions of the printer button and lights.

### 1.5.1 Feed Button

The **FEED** button is not simply for feeding label. It is able to act as a feed, pause, resume, restore and run button. The following table shows its functions.

Function	Description
Feed	Feed a blank label.
Pause	Pause printing, if pressed during printing.
Resume	Resume printing, if pressed in pause mode.
Restore	Restore the printer to the online mode, if pressed after fixing the error.
Run	Run the command of the system mode after selecting the command.

### 1.5.2 Status lights

The printer has two status lights: LED 1 and LED 2. They are helpful for checking printer's condition. Both lights have three colors: green, orange and red; they also have three blinking speed: fast, medium and slow. LED 1 glows green when the printer is working properly; it glows orange or red when the printer encounters issues. LED 2 indicates the issue the printer runs into. The following tables show the LEDs behavior and the condition they indicate.


Symbol	Blinking Speed	Blinking Interval
**	Fast	0.5 Second
*	Slow	2 Seconds
* LED2 + *LED1	Slow	LED2 & LED1 Blinking Interval at same time
* LED2 + LED1 *	Slow	LED2 & LED1 Blinking Interval at different timing

LED 2	LED 1	Description	LED indicate Label
Green	Green	The printer is ready to print.	V
Green	** Green	The printer is transmitting data.	
* Green	* Green	In pause.	V
* Green	Green *	The printer is writing data to the flash or USB memory. The USB memory is being initialized.	
Green	Orange	Head high temperature.	V
Green	** Orange	The print module is opened when the printer is turned on.	
Orange	Orange	Paper jam.	V
**Orange	** Orange	The media is out when the print data is sent to the printer. Paper end.	V
**Orange	Orange **	Ribbon end or ribbon error. (for thermal transfer models)	V
Red	Orange	The printhead is broken.	V
Red	*Orange	Communication error (RS-232C).	V
Red	**Orange	Cutter error (with optional cutter).	V
Red	Red	Cover (Thermal Head) open error during printing.	V
		An EEPROM for backup cannot be read or written properly.	
		A command has been fetched from an odd address.	
Red	* Red	Word data has been accessed from a place other than the boundary of the word data.	
		Long word data has been accessed from a place other than the boundary of the long word data.	
Red	** Red	Command error.	V
		Flash ROM on the CPU board error or USB memory error.	V
* Red	Red *	An erase error has occurred when formatting the USB memory.	
		Unable to save files due to insufficient USB memory.	

## 2 Accessories Installation

This chapter describes how to install accessories on the printer.

### 2.1 Cutter




A cutter is used to cut the label after it is printed out. A full cutter cuts a label off from a media roll.

To install a full cutter:


#### **Step 1. Remove the tear bar, top cover and middle frame**

This part describes how to dismantle your printer.


1. Open the top cover.
2. Press the **Module Release Latch** to open the print module.
3. Loosen and remove the two screws on each side of the tear bar.



4. Remove the tear bar from the printer.
5. Loosen and remove the two screws at the bottom of the tear bar.



- Loosen and remove the two screws on each side of the **Media Roll Holders**.




- Remove the middle frame along with the top cover.

## Step 2. Connect and secure the cutter to your printer


This part describes how to thread the cutter cable and wire, connect them to the main board and secure the cutter and reinstall the part you took off.

- Thread the cutter cable through the square hole to the right of the print module.



- Plug the cutter connector to the **J8** on the main board. **J8** is a white port

located to the right of the main board. Connect the ground wire (fork terminal) to the screw on the bottom-left corner after loosening the screw a bit and then tighten the screw to secure the wire.




3. Put the cutter on the print module.
4. Reinstall the middle frame along with the top cover. Make sure the cutter cable is inside the middle frame.
5. Reverse step 7-8 to secure the middle frame to the printer.
6. Position the cutter in front of the printer. Align the three screw holes of the cutter with the screw holes on each side of the platen roller and secure the cutter with three screws.

### Step 3. Test the cutter

This part describes how to use the cutter to cut your label.

1. Press the switch lock on the **Media Roll Holders** to slide them outward and place the media roll between the holders. Adjust the media roll so its print side is facing up and make sure it is clamped tightly by the holders.
2. Press the **Lock** button on the **Media Guides** to slide them outward.
3. Pull the media until it reaches the edge of the cutter plate. Put the media under the **Media Shaft** and center it between the **Media Guides**.
4. Thread the media into the slot of the cutter.
5. Close the print module and press down firmly at its both sides, until you hear a click.
6. Close the top cover.
7. Send a print job or press the **FEED** button to test if the cutter works.

## 2.2 Dispenser




A dispenser automatically removes the liner from the printed label. The dispenser sensor detects if a peeled label is taken away.

To install a dispenser:


### Step 1. Remove the tear bar, top cover and middle frame

This part describes how to dismantle your printer.


1. Open the top cover.
2. Push the **Module Release Latch** to open the print module.
3. Loosen and remove the two screws on each side of the tear bar to reveal the screw holes. You'll use those two screw holes to secure the dispenser later.



4. Remove the tear bar from the printer.
5. Loosen and remove the two screws at the bottom of the tear bar.



6. Loosen and remove the two screws on each side of the **Media Roll Holders**.




7. Remove the middle frame along with the top cover.

## Step 2. Connect and secure the dispenser to your printer


This part describes how to thread the dispenser cable and wire, connect them to the main board and secure the dispenser and reinstall the part you took off.

1. Thread the dispenser wire through the square hole to the right of the print module.



2. Plug the dispenser connector to the **J14** on the main board. **J14** is a red port

located to the rightmost of the main board.




3. Put the dispenser on the print module.
4. Reinstall the middle frame along with the top cover. Make sure the dispenser wire is inside the middle frame.
5. Secure the middle frame to the printer.
6. Open the dispenser and insert the bracket under the platen roller to position the dispenser in front of the printer.
7. Locate the two screw holes under each side of the bracket. They are the same screw holes used by the tear bar. Secure the dispenser with two screws.

### Step 3. Test the dispenser

This part describes how to use the dispenser to peel the liner.

1. Press the switch lock on the **Media Roll Holders** to slide them outward and place the media roll between the holders. Adjust the media roll so its print side is facing up, and make sure it is clamped tightly by the holders.
2. Press the **Lock** button on the **Media Guides** to slide them outward.
3. Pull the media until it reaches out of the printer. Put the media under the **Media Shaft** and center it between the **Media Guides**.
4. Remove 1-3 labels from the liner at the start of the media.
5. Close the print module and press down firmly at its both sides, until you hear a click.
6. Thread the liner into the slot of the dispenser, until the first label touches the dispenser plate.
7. Close the dispenser and close the top cover.
8. Send a print job or press the **FEED** button to test if the dispenser works.

## 2.3 Wireless LAN Module



The Wireless LAN module provides Wireless LAN connectivity for your printer.

To install a Wireless LAN module:

### Step 1. Dismantle your printer


This part describes how to remove the top cover, middle frame, tear bar and the print module.

1. Open the top cover.
2. Loosen and remove two screws on each side of the tear bar.
3. Remove the tear bar from your printer.
4. Loosen and remove four screws from the middle frame.
5. Remove the middle frame along with the top cover
6. Loosen the four screws from the print module.
7. Move the print module aside to reveal the space below the main board.


### Step 2. Secure the Wireless LAN card and connect it to the main board

This part describes how to secure the Wireless LAN card and connect it to the main board.

1. Plug the reflective sensor cable to the **Reflective Sensor** port of the Wireless LAN card.




2. Below the main board, you'll find two screw holes on the lower-right. Align the two holes on the Wireless LAN card with them and secure the card with two screws.



3. Plug the Wireless LAN cable 1 (white connector) to **J13**, which is the white port located to the lower-right of the main board.
4. Plug the Wireless LAN cable 2 (black connector) to **J15**, which is the black port located to the lower-right of the main board.

5. Tear off the back tape of the Wireless LAN antenna card and stick the card besides the panel board (LED board).
6. Use the clip to fasten the antenna card.
7. Attach the antenna to the **Antenna** port.




### Step 3. Reinstall the parts you took off

This part describes how to reinstall the parts you took off.

1. Reinstall the print module and secure it with four screws.
2. Reinstall the middle frame along with the top cover and secure it with four screws.
3. Reinstall the tear bar and secure it with two screws.
4. Close the top cover.

## 2.4 Bluetooth Module



The Bluetooth module provides Bluetooth connectivity for your printer.

To install a Bluetooth module:

### Step 1. Dismantle your printer


This part describes how to remove the top cover, middle frame, tear bar and the print module.

1. Open the top cover.
2. Loosen and remove two screws on each side of the tear bar.
3. Remove the tear bar from your printer.
4. Loosen and remove four screws from the middle frame.
5. Remove the middle frame along with the top cover
6. Loosen the four screws from the print module.
7. Move the print module aside to reveal the space below the main board.

### Step 2. Secure the Bluetooth card and connect it to the main board

This part describes how to secure the Bluetooth card and connect it to the main board.

1. Plug the Bluetooth cable (white connector) to the port on the Bluetooth card.
2. Below the main board, you'll find two screw holes on the lower-right. Align the two holes on the Bluetooth card with them and secure the card with two screws.



3. Plug the Bluetooth cable to **J15**, which is the black port located to the lower-right of the main board. Route the Bluetooth cable outside (right) of the row of connectors.


### **Step 3. Reinstall the parts you took off**

This part describes how to reinstall the parts you took off.

1. Reinstall the print module and secure it with four screws.
2. Reinstall the middle frame along with the top cover and secure it with four screws.
3. Reinstall the tear bar and secure it with two screws.
4. Close the top cover.

## 2.5 External Unwinder

An external unwinder can hold up to 8-inch outer diameter media roll. It allows you to print labels without frequently replacing media rolls.




To install an external unwinder:

1. Slide the **Unwinder Holders** into the **Holder Slots**, until the holders snap into the place.
2. Thread the power cord and the connection cable through the bottom slot of **Unwinder Base**, until they reach out of the front slot.
3. Insert the **Holder Shaft** into your media roll.
4. Do one of the following to assemble the **Holder Shaft** and the **Roll Stops**:

- If the inside diameter of the media roll is 1-inch, make sure the **Core Holders** are facing inward, and then insert the **Roll Stops** into each end of the **Holder Shaft**.
  - If the inside diameter of the media roll is 3-inch, make sure the **Core Holders** are facing outward and then insert the **Roll Stops** into each end of the **Holder Shaft**.
5. Place the **Holder Shaft** on the **Unwinder Holders**.
  6. Place the printer on the **Unwinder Base**. Fit the printer's rear rubber feet into the **Rubber Foot Slots**.
  7. Attach the power cord and the connection cable to the printer.
  8. Pull out the media and thread it through the rear slot of the printer.


## 2.6 Paper Support Roller



A paper support roller is used to prevent paper jam. It is placed between the **Media Shaft** and the **Media Roll Holders**. When paper is moving forward during the printing, it might be curled or crumpled and cause paper jam. The roller can hold the paper down to solve this problem. For thermal transfer media, we recommend you use the paper support roller if the label length is less than 45 mm, width is less than 50 mm, gap is more than 3 mm, and the media roll is outside wound.

To install a paper support roller:

1. Insert the right end of the rod to the hole of the right bracket holder.
2. Place the left end of the rod on the left bracket holder.



## 3 System Mode

The system mode consists of status light color combinations. It contains a list of commands for you to select and run.

To enter the system mode and run the command, do the following:

1. Turn off the printer.
2. Press and hold the **FEED** button, and turn on the printer.
3. Both status lights glow solid orange for a few seconds. Next, they turn to green shortly and then turn to other colors.
4. When status lights show the color combination you need, release the **FEED** button immediately.
5. Press the **FEED** button to run the command.

The following table is the command list of the system mode.

LED 1	LED 2	Command
Green	Red	<a href="#">Transmissive Sensor Calibration</a>
Green	Orange	<a href="#">Reflective Sensor Calibration</a>
Red	Red	<a href="#">Reset Your Printer</a>
Red	Orange	Reserved
Orange	Red	Reserved
Orange	Green	<a href="#">Self-Test and Dump Mode</a>

## 3.1 Media Sensor Calibration

Each type of media roll has its own label separators, such as gaps, holes, notches or black marks. Those separators need to be detected by media sensors, so the label can be printed in correct position. SATO WS TT printers provide transmissive and reflective sensor calibration for media detection. Do the following to use them.

1. Make sure the media is properly loaded, the print module is closed and the printer's power switch is set to the **OFF** position.
2. Press and hold the **FEED** button, and turn on the printer.
3. Both status lights glow solid orange for a few seconds. Next, they turn to green shortly and then turn to other colors. Do one of the following to select the sensor:
  - If you want to calibrate the transmissive sensor, when LED 1 turns to green and LED 2 turns to red, release the **FEED** button immediately.
  - If you want to calibrate the reflective sensor, when LED 1 turns to green and LED 2 turns to orange, release the **FEED** button immediately.
4. Press the **FEED** button. The media calibration is complete after the printer feeds 3-4 labels and stops.

## 3.2 Reset Your Printer

By resetting your printer, you can return your printer to the state it was in when you receive it. This can help you solve some problems caused by settings changed during the printing.

Do the following to reset your printer:

1. Turn off the printer.
2. Press and hold the **FEED** button and turn on the printer.
3. Both status lights glow solid orange for a few seconds. Next, they turn to green shortly and then turn to other colors. When both lights turn to red, release the **FEED** button immediately.
4. Press and hold the **FEED** button for 3 seconds and release it. Both status lights blink red three times and turn to solid orange for a few seconds. After the printer is reset, LED 2 goes out while LED 1 turns to solid green.



**Important** In step 4, if you do not hold the **FEED** button long enough, LED 2 will blink orange three times while LED 1 goes out. It means the printer is not reset.

## 3.3 Self-Test and Dump Mode


The printer can run a self-test to print a configuration label, which helps you understand the current settings of the printer.

### 3.3.1 Self-Test

1. Turn off the printer.
2. Press and hold the **FEED** button and turn on the printer.
3. Both status lights glow solid orange for a few seconds. Next, they turn to green shortly and then turn to other colors. When LED 1 turns to orange and LED 2 turns to green, release the **FEED** button.
4. Press the **FEED** button to print a configuration label.

Your printer has one emulation language: SZPL. The figure below shows its configuration label.

SBPL

LABEL PRINTER WITH FIRMWARE	
WS406TT-70.00.00.01 161102 SBPL	1
STANDARD RAM : 32M BYTES	2
AVAILABLE RAM : 3678K BYTES	3
FLASH TYPE : ON BOARD 16M BYTES	4
AVAILABLE FLASH : 2576K BYTES	5
NO. OF DL SOFT FONTS(FLASH) : 0	6
NO. OF DL SOFT FONTS(RAM) : 0	7
NO. OF DL SOFT FONTS(HOST) : 0	8
H. POSITION ADJUST.: 001A	9
GAP SENSOR	10
I-MARK: 0063 GAP: 0059	11
MAX LABEL HEIGHT: 38 INCHES	12
PRINT WIDTH: 812 DOTS	13
LAB LEN(TOP TO TOP): 79mm	14
SPEED: 5 IPS	15
DARKNESS: 2	16
THERMAL TRANSFER	17
PRINT DISTANCE: 19M	18
CUT COUNT:0	19
RS232: 9600, 8, N, 1P, XON/XOFF	20
MEDIA : NON-CONTINUOUS	21
REPRINT AFTER ERROR : ENABLED	22
BACKFEED ENABLED	23
CUTTER DISABLED	24
PEELER DISABLED	25
CUTTER/PEELER OFFSET: 0 <+0.01mm>	26
IP ADDRESS: 0.0.0.0	27
SUBNET MASK: 0.0.0.0	28
GATEWAY: 0.0.0.0	29
MAC ADDRESS: 78-5F-4C-00-04-6B	30
DHCP: ENABLED	31
DHCP CLIENT ID: FFFFFFFFFFFFFFFF	32
FFFFFFFFFFFFFFF	
DHCP HOST NAME:	34
SNMP: ENABLED	35
SOCKET COMM.: ENABLED	36
SOCKET PORT: 9100	37
IPV6 MODE: MANUAL	38
IPV6 TYPE: NONE	39
IPV6 ADDRESS: 0000:0000:0000:0000:	40
0000:0000:0000:0000:	
LINK LOCAL : 0000:0000:0000:0000:	41
0000:0000:0000:0000:	
PRODUCT SN: 000AH401009	42
USB SN: AH4850501009	43
ot(0,0)<0.1dot,0.01mm>	44
rm(0,0)<1+ 0-,0.01mm>	45
sm(0,0)<1+ 0-,0.01mm>	46
rv(133,91,41)<0.01v<P>	47
sv(270,159,110)<0.01v<P>	48
bv(318,41,277)<0.01v<P>	49
rso(0)<0.01mm>	50
ss0(0)<0.01mm>	51
	52
	53
	54
	55
	56
	57

**1. Version Information**

The firmware version and its build date.

**2. Standard RAM**

Total SDRAM size.

**3. Available RAM**

RAM is able to be used.

**4. Flash Type**

The flash memory type and size.

**5. Available Flash**

Flash is able to be used.

**6. No of DL soft fonts (FLASH)**

The number of fonts is downloaded in Flash.

**7. No of DL soft fonts (RAM)**

The number of fonts is downloaded in RAM.

**8. No of DL soft fonts (HOST)**

The number of fonts is downloaded in USB HOST.

**9. H. Position Adjust**

Move the print position horizontally.

**10. Sensor Type**

The media sensor type. It is Gap(transmissive) or I-Mark(reflective) sensor.

**11. Label-less Calibration Value**

Check if a label-less calibration has been performed on the printer. If not, the value is 0000.

**12. Max Label Height**

The max label length you can print at a time. For 200 dpi models, it is 100 inches; for 300 dpi models, it is 50 inches.

**13. Print Width**

The print width in dots.

**14. Lab Len (Top to Top)**

For non-continues media, it is the length between the tops of two labels.

**15. Speed**

The speed of printing. The unit is inch per second (ips).

**16. Darkness**

The current darkness.

**17. Print Method**

It is either thermal transfer (TT) or direct thermal (DT) printing. TT requires ribbons and DT doesn't.

**18. Print Length**

The total print length.

**19. Cut Count**

It counts the times the cutter cuts.

**20. RS232 Protocol**

It lists RS-232C settings in the following order: baud rate, data length, parity check, stop bit and flow control.

**21. Media**

The media type in use.

**22. Reprint After Error**

When it is enabled, the printer reprints the label after the error fixed if it is printed incorrectly due to the error.

**23. Backfeed Enabled/Disabled**

Enable or disable backfeed during the printing process. When it is enabled, the printer moves the paper forward in a predefined length 1 second after printing, and pulls the paper back in a predefined length once the printing begins again. When it is disabled, the printer won't move the paper at all.

**24. Cutter Enabled/Disabled**

Enable or disable the cutter during the printing process.

**25. Dispenser Enabled/Disabled**

Enable or disable the dispenser during the printing process.

**26. Cutter/Dispenser Offset**

Move the cutting line or the peeling position forward or backward. The value in the angle brackets is the offset unit.

**27. IP Address**

The static IP address of the printer. The default value is "192.168.1.1".

**28. Subnet Mask**

The manually specified subnet mask of the printer. The default value is “255.255.255.0.”

**29. Gateway**

The manually specified gateway of the printer. The default value is “0.0.0.0.”

**30. MAC Address**

The unique address assigned to the printer that connects to the internet.

**31. DHCP**

When DHCP is enabled, it assigns an IP address to the printer automatically.

**32. DHCP Client ID**

It is an arbitrary value sent to the DHCP server to reserve an IP address for the printer.

**33. DHCP Host Name**

The name of a DHCP client.

**34. SNMP**

When it is enabled, the host gets or sets parameters registered as SNMP entities.

**35. Socket Communication**

When it is enabled, the host communicates with the printer via the socket.

**36. Socket Port**

The socket number of the printer.

**37. IPv6 Mode**

It determines how you get the IPv6 address of your printer. There are three modes: MANUAL, DHCPv6 or AUTO.

**38. IPv6 Type**

It is the IPv6 address type of your printer. There are four types: NONE, NORMAL, EUI and ANY.

**39. IPv6 Address**

The static IPv6 address of your printer.

**40. Link Local**

The IPv6 address that used in a network segment. It is allocated automatically.

**41. Product SN**

The serial number of product.

**42. USB SN**

The Serial number of USB host.

**43. TPH and Cutter Offset**

For developers to debug.

**44. Reflective Sensor Gap Calibration**

For developers to debug.

**45. See-Through Sensor Gap Calibration**

For developers to debug.

**46. Reflective Sensor Profile**

For developers to debug.

**47. See-Through Sensor Profile**

For developers to debug.

**48. Ribbon Sensor Profile**

For developers to debug.

**49. Reflective Sensor Offset**

For developers to debug.

**50. See-Through Sensor Offset**

For developers to debug.

**51-56. TPH Test Pattern**

You can use them to check broken pins on the printhead.

If your printer has a Wireless LAN module, your SBPL configuration label will contain the following entries:

WLAN FW VERSION: 1.10	1
DATE: 2016.11.15	
WLAN IP ADDRESS: 0.0.0.0	2
WLAN SUBNET MASK: 0.0.0.0	3
WLAN GATEWAY: 0.0.0.0	4
WLAN MAC ADDRESS: 00-80-92-4F-39-22	5
WLAN DHCP: AUTO	6
WLAN DHCP HOSTNAME: 00-80-92-4F-39-2 : 2	7
WLAN SOCKET PORT: 9100	8
WLAN SSID: SATO_PRINTER	9
WLAN MODE: Infrastructure	10
WLAN COUNTRY CODE: USA	11
WLAN CHANEL: AUTO	12
WLAN NETWORK AUTHENTICATION: Open	13
WLAN WEP: OFF	14

#### 1. FW Version and Date

Wireless LAN card firmware version and date.

#### 2. IP Address

The IP address of your printer. When DHCP is enabled, it shows the automatically assigned IP address; when DHCP is disabled, it shows the manually specified IP address.

#### 3. Subnet Mask

The manually specified IPv4 subnet mask of your printer.

#### 4. Gateway

The gateway of your printer. When DHCP is enabled, it shows the automatically assigned gateway; when DHCP is disabled, it shows the manually specified gateway.

#### 5. MAC Address

The unique address assigned to your printer that connects to the internet.

#### 6. DHCP

When DHCP is enabled, it assigns an IP address to your printer automatically.

#### 7. DHCP Hostname

It is the name of a DHCP client

#### 8. Socket Port

The socket number of your printer.

**9. SSID**

Short for service set identifier. It is the name of a wireless local area network.

**10. Mode**

It determines how you connect your printer to a network.

*Infrastructure*: If you connect through an access point, select this.

*Ad hoc*: if you connect through a device which has connected to a network, select this. In Ad hoc mode, you can only use Open authentication.

**11. Country Code**

The country or region.

**12. Channel**

The Wireless LAN channel.

**13. Network authentication**

It allows any device to authenticate to an access point (AP) and gain access to a network.

**14. WEP**

*ON*: Encrypt data to WEP encryption. *OFF*: WEP encryption off.

If your printer has a Bluetooth module, your SBPL configuration label will contain the following entries:

```

BT DEVICE: SATO WS4 _____1
BT PIN: 0000 _____2
BT MAC: 00-0A-3A-32-05-60 _____3
 _____4
  
```

**1. BT Device**

The Bluetooth device name of your printer.

**2. BT PIN**

The Bluetooth passkey of your printer.

**3. BT MAC Address**

The Bluetooth MAC address of your printer.


**4. BT MAC Address Barcode**

The barcode of the Bluetooth MAC address of your printer.

■ SZPL

```

LABEL PRINTER WITH FIRMWARE
WS408TT-70.00.00.01 161102 SZPL _____ 1
STANDARD RAM : 32M BYTES _____ 2
AVAILABLE RAM : 3678K BYTES _____ 3
FLASH TYPE : ON BOARD 16M BYTES _____ 4
AVAILABLE FLASH : 2576K BYTES _____ 5
NO. OF DL SOFT FONTS(FLASH) : 0 _____ 6
NO. OF DL SOFT FONTS(RAM) : 0 _____ 7
NO. OF DL SOFT FONTS(HOST) : 0 _____ 8
H. POSITION ADJUST.: 001A _____ 9
GAP SENSOR _____ 10
I-MARK: 0063 GAP: 0059 _____ 11
MAX LABEL HEIGHT: 38 INCHES _____ 12
PRINT WIDTH: 812 DOTS _____ 13
LAB LEN(TOP TO TOP): 79mm _____ 14
SPEED: 5 IPS _____ 15
ABS. DARKNESS: 10 _____ 16
TRIM. DARKNESS: 0 _____ 17
THERMAL TRANSFER _____ 18
PRINT DISTANCE: 21M _____ 19
CUT COUNT:0 _____ 20
RS232: 9600, 8, N, 1P, XON/XOFF _____ 21
CARET CONTROL CHAR : <^> 5EH _____ 22
DELIMITER CONTROL CHAR : <, > 2CH _____ 23
TILDE CONTROL CHAR : <~> 7EH _____ 24
CODE PAGE : USA1 _____ 25
MEDIA : NON-CONTINUOUS _____ 26
REPRINT AFTER ERROR : ENABLED _____ 27
BACKFEED ENABLED _____ 28
CUTTER DISABLED _____ 29
PEELER DISABLED _____ 30
CUTTER/PEELER OFFSET: 0 <+-0.01mm> _____ 31
IP ADDRESS: 0.0.0.0 _____ 32
SUBNET MASK: 0.0.0.0 _____ 33
GATEWAY: 0.0.0.0 _____ 34
MAC ADDRESS: 78-5F-4C-00-04-6B _____ 35
DHCP: ENABLED _____ 36
DHCP CLIENT ID: FFFFFFFFFFFFFFFF _____ 37
                    FFFFFFFFFFFFFFFF
DHCP HOST NAME: _____ 38
SNMP: ENABLED _____ 39
SOCKET COMM.: ENABLED _____ 40
SOCKET PORT: 9100 _____ 41
IPV6 MODE: MANUAL _____ 42
IPV6 TYPE: NONE _____ 43
IPV6 ADDRESS: 0000:0000:0000:0000: _____ 44
                    0000:0000:0000:0000
LINK LOCAL : 0000:0000:0000:0000: _____ 45
                    0000:0000:0000:0000
PRODUCT SN: 000AH401009 _____ 46
USB SN: AH4B50501009 _____ 47
ot(0,0)<0.1dot,0.01mm> _____ 48
rm(0,0)<1+ 0-,0.01mm> _____ 49
sm(0,0)<1+ 0-,0.01mm> _____ 50
rv(133,91,41)<0.01u><P> _____ 51
sv(270,159,110)<0.01u><P> _____ 52
bv(318,41,277)<0.01u><P> _____ 53
rso(0)<0.01mm> _____ 54
rso(0)<0.01mm> _____ 55
THIS IS FONT A. 0123ABCabc _____ 56
THIS IS FONT B. 0123ABCabc _____ 57
THIS IS FONT C. 0123ABCabc _____ 58
THIS IS FONT D. 0123ABCabc _____ 59
THIS IS FONT E. 0123ABCabc _____ 60
THIS IS FONT F. 0123ABCabc _____ 61
THIS IS FONT G. _____ 62
THIS IS FONT H. 0123ABC _____ 63
This Is Font CG Triumv Bd Condensed. _____ 64


_____ 65
_____ 66
_____ 67
_____ 68
_____ 69
_____ 70

```

**1. Version Information**

The firmware version and its build date.

**2. Standard RAM**

Total SDRAM size.

**3. Available RAM**

RAM is able to be used.

**4. Flash Type**

The flash memory type and size.

**5. Available Flash**

Flash is able to be used.

**6. No of DL soft fonts (FLASH)**

The number of fonts is downloaded in Flash.

**7. No of DL soft fonts (RAM)**

The number of fonts is downloaded in RAM.

**8. No of DL soft fonts (HOST)**

The number of fonts is downloaded in USB HOST.

**9. H. Position Adjust**

Move the print position horizontally.

**10. Sensor Type**

The media sensor type. It is Gap(transmissive) or I-Mark(reflective) sensor.

**11. Label-less Calibration Value**

Check if a label-less calibration has been performed on the printer. If not, the value is 0000.

**12. Max Label Height**

The max label length you can print at a time. For 200 dpi models, it is 100 inches; for 300 dpi models, it is 50 inches.

**13. Print Width**

The print width in dots.

**14. Lab Len (Top to Top)**

For non-continues media, it is the length between the tops of two labels. You can also use the SZPL command  $\wedge LL$  to define it. By default, it is 10 mm.

**15. Speed**

The speed of printing. The unit is inch per second (ips).

**16. ABS. Darkness**

The current darkness. You can use the SZPL command `~SD` to define it.

**17. Trim. Darkness**

The adjustment of the current darkness. You can use the SZPL command `^MD` to define it.

**18. Print Method**

It is either thermal transfer (TT) or direct thermal (DT) printing. TT requires ribbons and DT doesn't.

**19. Print Length**

The total print length.

**20. Cut Count**

It counts the times the cutter cuts.

**21. RS232 Protocol**

It lists RS-232C settings in the following order: baud rate, data length, parity check, stop bit and flow control.

**22-24. Control Character**

The control character the printer is using.

**25. Code Page**

The character set table.

**26. Media**

The media type in use.

**27. Reprint After Error**

When it is enabled, the printer reprints the label after the error fixed if it is printed incorrectly due to the error.

**28. Backfeed Enabled/Disabled**

Enable or disable backfeed during the printing process. When it is enabled, the printer moves the paper forward in a predefined length 1 second after printing, and pulls the paper back in a predefined length once the printing begins again. When it is disabled, the printer won't move the paper at all.

**29. Cutter Enabled/Disabled**

Enable or disable the cutter during the printing process.

**30. Dispenser Enabled/Disabled**

Enable or disable the dispenser during the printing process.

**31. Cutter/Dispenser Offset**

Move the cutting line or the peeling position forward or backward. The value in the angle brackets is the offset unit.

**32. IP Address**

The static IP address of the printer. The default value is "192.168.1.1".

**33. Subnet Mask**

The manually specified subnet mask of the printer. The default value is "255.255.255.0."

**34. Gateway**

The manually specified gateway of the printer. The default value is "0.0.0.0."

**35. MAC Address**

The unique address assigned to the printer that connects to the internet.

**36. DHCP**

When DHCP is enabled, it assigns an IP address to the printer automatically.

**37. DHCP Client ID**

It is an arbitrary value sent to the DHCP server to reserve an IP address for the printer.

**38. DHCP Host Name**

The name of a DHCP client.

**39. SNMP**

When it is enabled, the host gets or sets parameters registered as SNMP entities.

**40. Socket Communication**

When it is enabled, the host communicates with the printer via the socket.

**41. Socket Port**

The socket number of the printer.

**42. IPv6 Mode**

It determines how you get the IPv6 address of your printer. There are three modes: MANUAL, DHCPv6 or AUTO.

**43. IPv6 Type**

It is the IPv6 address type of your printer. There are four types: NONE, NORMAL, EUI and ANY.

**44. IPv6 Address**

The static IPv6 address of your printer.

**45. Link Local**

The IPv6 address that used in a network segment. It is allocated automatically.

**46. Product SN**

The serial number of product.

**47. USB SN**

The Serial number of USB host.

**48. TPH and Cutter Offset**

For developers to debug.

**49. Reflective Sensor Gap Calibration**

For developers to debug.

**50. See-Through Sensor Gap Calibration**

For developers to debug.

**51. Reflective Sensor Profile**

For developers to debug.

**52. See-Through Sensor Profile**

For developers to debug.

**53. Ribbon Sensor Profile**

For developers to debug.

**54. Reflective Sensor Offset**

For developers to debug.

**55. See-Through Sensor Offset**

For developers to debug.

**56-64. Font Image**

You can use them as the reference to check your label font.

**65-70. TPH Test Pattern**

You can use them to check broken pins on the printhead.

If your printer has a Wireless LAN module, your SZPL configuration label will contain the following entries:

INTERFACE: DOWN	1
DHCP: ON	2
IP: 192.168.1.172:2000	3
NETMASK: 255.255.255.0	4
GATEWAY: 192.168.1.1	5
SSID: ASUS	6
COUNTRY CODE: USA	7
CHANNEL: 0 (AUTO)	8
JOIN: AP	9
MAC: 00:06:66:21:89:0d	10

### 1. Interface

It detects if your printer connects to a network. When it's online, it shows "UP"; when it's offline, it shows "DOWN."

### 2. DHCP

When DHCP is enabled, it assigns an IP address to your printer automatically.

### 3. IP Address

The IP address of your printer. When DHCP is enabled, it shows the automatically assigned IP address; when DHCP is disabled, it shows the manually specified IP address.

### 4. Netmask

The netmask of your printer. When DHCP is enabled, it shows the automatically assigned netmask; when DHCP is disabled, it shows the manually specified netmask.

### 5. Gateway

The gateway of your printer. When DHCP is enabled, it shows the automatically assigned gateway; when DHCP is disabled, it shows the manually specified gateway.

### 6. SSID

Short for service set identifier. It is the name of a wireless local area network.

### 7. Country Code

The country or region.

### 8. Channel

The Wireless LAN channel.

### 9. Join


It determines how you connect your printer to a network. It's either AP (Access

Point) or Ad hoc.

**10. MAC Address**

The unique address assigned to your printer that connects to the internet.

If your printer has a Bluetooth module, your SZPL configuration label will contain the following entries:



**1. BT Device**

The Bluetooth device name of your printer.

**2. BT PIN**

The Bluetooth passkey of your printer.


**3. BT MAC Address**

The Bluetooth MAC address of your printer.

**4. BT MAC Address Barcode**


The barcode of the Bluetooth MAC address of your printer.

SDPL

  
**R8/E94/PC/PCA/PCB/LG**  
**Courier Fonts:**  
 ASD Smooth font (18 points) - 12  
 ASD Smooth font (14 points) - 123456789  
 ASD Smooth font (12 points) - 123456789 ABCa  
 ASD Smooth font (10 points) - 123456789 ABCabcXyz  
 ASD Smooth font (8 points) - 123456789 ABCabcXyz  
 ASD Smooth font (6 points) - 123456789 ABCabcXyz  
 ASD Smooth font (4 points) - 123456789 ABCabcXyz  
 ASD Smooth font (2 points) - 123456789 ABCabcXyz  
**123456789**  
 This is internal font 7. OCR-A ABCabc  
**THIS IS INTERNAL FONT**  
 THIS IS INTERNAL FONT 5. 012345678  
 THIS IS INTERNAL FONT 4. 012345678  
 THIS IS INTERNAL FONT 3. 0123456789 ABCABC  
 This is internal font 2. 0123456789 ABCabcXyz  
 This is internal font 1. 0123456789 ABCabcXyz  
 This is internal font 0. 0123456789 ABCabcXyz  
 seo(0)<0 01nn>  
 seo(0)<0 01nn>  
 bu(318.41.277)<0 01u><P>  
 eu(270.159.110)<0 01u><P>  
 ru(133.91.41)<0 01u><P>  
 su(0.0)<1+ 0- 0.01nn>  
 ru(0.0)<1+ 0- 0.01nn>  
 ol(0.0)<0 1dot.0 01nn>  
 USB SN: F44550501003  
 PRODUCT SN: 000F4401003  
 LINK LOCAL : 0000 0000 0000 0000  
 0000 0000 0000 0000  
 0000 0000 0000 0000  
 IPV6 ADDRESS: 0000 0000 0000 0000  
 IPV6 TYPE: NONE  
 IPV6 MODE: MANUAL  
 SOCKET PORT: 9100  
 SOCKET COMM: ENABLED  
 SNMP: ENABLED  
 DHCP HOST NAME:  
 FFFFFFFFFFFFFFFF  
 DHCP CLIENT ID: FFFFFFFFFFFFFFFF  
 DHCP: ENABLED  
 MAC ADDRESS: 70-SF-4C-00-04-6B  
 GATEWAY: 0 0 0 0  
 SUBNET MASK: 0 0 0 0  
 IP ADDRESS: 0 0 0 0  
 CUTTER/PEELER OFFSET: 0 (+-0 01nn)  
 PEELER DISABLED  
 CUTTER DISABLED  
 BACKFEED ENABLED  
 REPRINT AFTER ERROR: ENABLED  
 MEDIA: NON-CONTINUOUS  
 STD CTRL CODES  
 CODE PAGE: PC-850  
 RS232: 9600.8.N.IP.XON/XOFF(SOFTWARE)  
 CUT COUNT: 0  
 PRINT DISTANCE: 20M  
 THERMAL TRANSFER  
 DARKNESS: 6  
 SPEED: 5 IPS  
 LAB LEN(TOP TO TOP): 79mm  
 PRINT WIDTH: 012 DOTS  
 MAX LABEL HEIGHT: 30 INCHES  
 I-MARK: 0063 GAP: 0059  
 GAP SENSOR  
 H. POSITION ADJUST: 001A  
 NO. OF DL SOFT FONTS(HOST): 0  
 NO. OF DL SOFT FONTS(RAM): 0  
 NO. OF DL SOFT FONTS(FLASH): 0  
 AVAILABLE FLASH: 2576K BYTES  
 FLASH TYPE: ON BOARD 16M BYTES  
 AVAILABLE RAM: 3678K BYTES  
 STANDARD RAM: 32M BYTES  
 US40BT-70 00 00 01 161182 SDPL  
 LABEL PRINTER WITH FIRMWARE

■ SEPL

```

LABEL PRINTER WITH FIRMWARE
WS408TT-70.00.00.01 161102 SEPL
STANDARD RAM : 32M BYTES
AVAILABLE RAM : 3678K BYTES
FLASH TYPE : ON BOARD 16M BYTES
AVAILABLE FLASH : 2576K BYTES
NO. OF DL SOFT FONTS(FLASH) : 0
NO. OF DL SOFT FONTS(RAM) : 0
NO. OF DL SOFT FONTS(HOST) : 0
H. POSITION ADJUST.: 001A
GAP SENSOR
I-MARK: 0063 GAP: 0059
MAX LABEL HEIGHT: 38 INCHES
PRINT WIDTH: 812 DOTS
LAB LEN(TOP TO TOP): 79mm
SPEED: 5 IPS
DARKNESS: 5
THERMAL TRANSFER
PRINT DISTANCE: 20M
CUT COUNT:0
RS232: 9600, 8, N, 1P, XON/XOFF
CODE PAGE : English (437)
MEDIA : NON-CONTINUOUS
REPRINT AFTER ERROR : ENABLED
BACKFEED ENABLED
CUTTER DISABLED
PEELER DISABLED
CUTTER/PEELER OFFSET: 0 <+-0.01mm>
IP ADDRESS: 0.0.0.0
SUBNET MASK: 0.0.0.0
GATEWAY: 0.0.0.0
MAC ADDRESS: 78-5F-4C-00-04-6B
DHCP: ENABLED
DHCP CLIENT ID: FFFFFFFFFFFFFFFF
FFFFFFFFFFFFFFF
DHCP HOST NAME:
SNMP: ENABLED
SOCKET COMM.: ENABLED
SOCKET PORT: 9100
IPV6 MODE: MANUAL
IPV6 TYPE: NONE
IPV6 ADDRESS: 0000:0000:0000:0000:
0000:0000:0000:0000
LINK LOCAL : 0000:0000:0000:0000:
0000:0000:0000:0000
PRODUCT SN: 000AH401009
USB SN: AH4B50501009
ot(0,0)<0.1dot,0.01mm>
rm(0,0)<1+ 0-,0.01mm>
sm(0,0)<1+ 0-,0.01mm>
rv(133,91,41)<0.01v><P>
sv(270,159,110)<0.01v><P>
bv(318,41,277)<0.01v><P>
rso(0)<0.01mm>
sso(0)<0.01mm>
This is internal font 1. 0123456789 ABCabcXyz
This is internal font 2. 0123456789 ABCabcXyz
This is internal font 3. 0123456789 ABCabcXyz
This is internal font 4. 0123456789 ABCXYZ
THIS IS INTERNAL FONT



```

■ SIPL

```

LABEL PRINTER WITH FIRMWARE
WS408TT-70.00.00.01 161102 SIPL
STANDARD RAM : 32M BYTES
AVAILABLE RAM : 3678K BYTES
FLASH TYPE : ON BOARD 16M BYTES
AVAILABLE FLASH : 2576K BYTES
NO. OF DL SOFT FONTS(FLASH) : 0
NO. OF DL SOFT FONTS(RAM) : 0
NO. OF DL SOFT FONTS(HOST) : 0
H. POSITION ADJUST.: 001A
GAP SENSOR
I-MARK: 0063 GAP: 0059
MAX LABEL HEIGHT: 38 INCHES
PRINT WIDTH: 812 DOTS
LAB LEN(TOP TO TOP): 79mm
SPEED: 5 IPS
DARKNESS: 10
THERMAL TRANSFER
PRINT DISTANCE: 20M
CUT COUNT:0
RS232: 9600, 8, N, 1P, XON/XOFF
MEDIA : NON-CONTINUOUS
REPRINT AFTER ERROR : ENABLED
BACKFEED ENABLED
CUTTER DISABLED
PEELER DISABLED
CUTTER/PEELER OFFSET: 0 <+-0.01mm>
IP ADDRESS: 0.0.0.0
SUBNET MASK: 0.0.0.0
GATEWAY: 0.0.0.0
MAC ADDRESS: 78-5F-4C-00-04-6B
DHCP: ENABLED
DHCP CLIENT ID: FFFFFFFFFFFFFFFF
                FFFFFFFFFFFFFFFF
DHCP HOST NAME:
SNMP: ENABLED
SOCKET COMM.: ENABLED
SOCKET PORT: 9100
IPV6 MODE: MANUAL
IPV6 TYPE: NONE
IPV6 ADDRESS: 0000:0000:0000:0000:
                0000:0000:0000:0000
LINK LOCAL : 0000:0000:0000:0000:
                0000:0000:0000:0000
PRODUCT SN: 000AH401009
USB SN: AH4B50501009
ot(0,0)<0.1dot,0.01mm>
rn(0,0)<1+ 0-,0.01mm>
sn(0,0)<1+ 0-,0.01mm>
rv(133,91,41)<0.01v><P>
sv(270,159,110)<0.01v><P>
bv(318,41,277)<0.01v><P>
rso(0)<0.01mm>
sso(0)<0.01mm>

```



## 3.3.2 Dump Mode

The printer enters Dump mode after running a self-test. In this mode, characters are printed in hexadecimal codes, allowing users and engineers to debug the system.

To return to the online mode:

- Turn off the printer and turn it on again.
- In Printer Utility 2013, in the **Navigation** pane, click **Tool**. In the **Properties** pane, click **Reboot Printer** and click **Send**.


This is applicable for SZPL, SDPL and SEPL.

## 4 SATO WS4 Printer Utility


SATO WS4 Printer Utility provides a user-friendly interface to configure your printer. You can define properties, update firmware and send commands in SATO WS4 Printer Utility.

### 4.1 Install SATO WS4 Printer Utility


1. Insert the CD into your CD or DVD drive.
2. Locate the installation file on the CD and click it.
3. In the **SATO WS4 Printer Utility** dialog box, click **Next**.




4. In this dialog box, follow the instructions to choose the installation path and then click **Next**.



5. In this dialog box, click **Next**.




6. After the installation of SATO WS4 Printer Utility is complete, click **Close**.




## 4.2 Work with SATO WS4 Printer Utility

Start SATO WS4 Printer Utility. Its interface looks like this:



- **Menu bar** It includes SATO WS4 Printer Utility menus.
- **Toolbar** It provides ports, port settings, emulation languages, printer dpi and printer status.
- **Navigation Pane** You can switch between the listed items to view their tabs.
- **Properties Pane** You can view and manage printer properties or perform tasks.

### 4.2.1 Menu bar



There are three menus in the menu bar: **File**, **Setting** and **Help**.

#### File

- **Export** Export your printer settings to an XML file,




including all parameters, port settings and firmware information.


- **Import** Import printer settings from an XML file.
- **Exit** Exit SATO WS4 Printer Utility.

## Setting

- **Auto Detect USB** When you connect your printer to a computer with a USB cable, SATO WS4 Printer Utility automatically detects it and shows the USB information in the **Port Name** and **Port Information**. By default, it is enabled.



- **Communication**




It includes **Write Timeout** and **Read Timeout**. They determine how long your computer (or other devices) waits printer’s response when it attempts to write or read data to your printer. The default value is 15 seconds, meaning that the computer waits 15 seconds and displays an error message if it doesn’t receive any response.

- **Progress Form**



When **Add Date/Time information** is enabled, the current date and time are added into the message in the **Download Firmware** dialog box.

- **Language**




It is the language of SATO WS4 Printer Utility interface. You can select **Windows's System Default, English** or **Simplified Chinese**. By default, it uses your system default.

## Help

- **Contents** The help content of SATO WS4 Printer Utility. You can press F1 to display it.
- **About** The version and copyright information about SATO WS4 Printer Utility.




## 4.2.2 Toolbar



The toolbar has two rows. The first row includes three items.

- **Input/Output Port** The port you use for the data transmission between the computer and your printer.
- **Setting** You can click it to configure the port settings.
- **Port Name** It shows the port name.
- **Port Information** It shows the port information.

SATO WS4 Printer Utility provides three ports for data transmission.



## ■ USB


It shows the USB information in the **Port Name** and **Port Information** as soon as the computer detects your printer. By default, the computer automatically detects the **USB** port. You can select the printer you want if your computer is connected to multiple printers



via USB. Click **Search** to search the hot-plugging USB printer.



## ■ COM


It is the serial port and related to the **COM** tab in **Parameter Setting**. The settings of the **COM** port need to be the same as those in the **COM** tab, except for **Port Name**, which lets you select the **COM** port you want if your computer is connected to multiple printers via COM. If you want to reset all of COM settings, click **Default**.



## ■ LAN

It is the Ethernet port and related to the **LAN** tab in **Parameter Setting**. It supports IPv4 and IPv6 addresses. For more information about Setting up a network connection, see [Set up LAN connection](#), [Set up IPv6 connection](#) and [Set up WLAN connection](#).





The second row of the toolbar includes six items.

- **Printer Model** Printer models.
- **Printer Emulation** The emulation language of your printer. The emulation you choose affects the tabs displayed in the **Properties** pane.
- **Printer DPI** The print resolution of your printer. It provides 203 dpi and 300 dpi.
- **Sync** Get the current settings of **Printer Model**, **Printer Emulation** and **Printer DPI** from your printer.
- **Get Status** Detect if your printer is ready for use.
- **Printer Status** It shows the result of **Get Status**.

## Printer status

Status	Description
ON LINE (Ready)	The top cover (head) was closed in the online mode.
HEAD OPEN	The top cover (head) was opened in the online mode.
ON LINE (Operating)	The printer is operating.
ACCESSED BY OTHER	Exclusively accessed by other host.
PAUSE	In pause.
ON LINE (Waiting for Stripping)	Waiting for stripping.
COMMAND ERROR	A command error was found while analyzing the command.
COMMS ERROR	A parity error, overrun error or framing error occurred during the RS-232C transmission.

Status	Description
PAPER JAM	A paper jam occurred during paper feed.
CUTTER ERROR	The cutter is experiencing issues.
NO PAPER	The label has run out.
HEAD OPEN ERROR	Attempt to feed or issue the label with the top cover (head) open.
HEAD ERROR	A broken pin has been found on the thermal head.
EXCESS HEAD TEMP	The thermal head temperature has become excessively high.
NO PAPER (Last label has been issued)	The last label has been issued properly and the label has run out.
MEMORY WRITE ERROR	An error has occurred while writing data into the flash ROM or USB memory.
FORMAT ERROR	An erase error has occurred in formatting the flash ROM or USB memory.
MEMORY FULL	Saving failed because of the insufficient capacity of the flash ROM or USB memory.
SAVING	In font or PC command save mode. (to flash ROM or to USB memory) The flash ROM or USB memory is being initialized.
SAVING ERROR	An EEPROM for backup cannot be read or written properly.
UPDATING FIRMWARE NOW	The printer is updating firmware.
BLUETOOTH ERROR	Bluetooth initialization error. Bluetooth setting parameter error.
WIRELESSLAN ERROR	WirelessLAN initialization error. WirelessLAN setting parameter error.
UPDATING FIRMWARE ERROR	An error occurred during the firmware update.
UNKNOWN	The status is unknown.

## 4.2.3 Navigation Pane

The **Navigation** pane includes four items: **Parameter Setting**, **Download**, **Tool** and **Font**. Each item has its own tabs, and each tab has a **Send**, **Get**, **Add** or **Delete** button (Some of them only have **Send**). **Send** is to send your settings to your printer; **Get** is to get the current settings of your printer; **Add** is to add file to the list object; **Delete** is to delete file from the list object. You can also right-click in the **Properties** pane and select **Send**, **Get**, **Add** or **Delete** in the shortcut menu. Each time you click **Send**, your printer restarts to apply the change.



**Important** You can send data via all ports, but can only get data via the **USB**, **COM** and **LAN** ports.

---

## Parameter Setting


**Parameter Setting** is used to configure printer settings. It includes six tabs: **General**, **COM**, **LAN**, **IPv6**, **WLAN** and **Bluetooth**.

### General

The **General** tab provides general printer settings. It is related to the emulation language you choose. Each language provides its own properties.

#### ■ SBPL

**SBPL** provides settings grouped in the **Supply**, **Control**, **Action**, **Image**, **Label**, **Position Adjustment**, **Protocol** and **Nonstandard Protocol** area.




Property Name	Description
Sensor Type	It is the media sensor you are using. It includes <b>I-MARK</b> , <b>GAP</b> and <b>None</b> . When you perform media calibration, the sensor is set to the one you select.
Ribbon Sensor	<b>Thermal Transfer</b> Your printer uses the ribbon sensor to detect the ribbon, it is mean <b>Thermal Transfer (TT)</b> . <b>Direct Thermal</b> Disable the ribbon sensor, it is mean <b>Direct Thermal (DT)</b> .
Feed Key	It defines the action of the <b>FEED</b> button. <b>Feed</b> Your printer feeds a blank label each time the button is pressed. <b>Reprint</b> Your printer reprints the last label each time the button is pressed.
Head Check (Power on)	<b>Enable</b> Your printer checks broken pins on the printhead automatically once your printer is turned on. <b>Disable</b> Disable the auto head check.
Auto Calibration	<b>ON (Power on)</b> Your printer automatically calibrates media using a media sensor once it restarts or is turned on. <b>ON (Head close)</b> Your printer automatically calibrates media using a media sensor every time you close the print module when the printer is turned on.

Property Name	Description
	<p><b>ON (Power on and Head close)</b> Your printer automatically calibrates media using a media sensor after power on and every time you close the print module when the printer is turned on.</p> <p><b>OFF</b> You need to manually calibrate media using a media sensor as you change the media, or your printer won't work properly.</p>
Reprint After Error	<p><b>Enable</b> Your printer when caused by the error condition. The label is reprinted as soon as the error condition is corrected.</p> <p><b>Disable</b> Disable the reprint after error.</p>
Print Darkness	Adjust the darkness relative to the current darkness setting. The range is +1~ +5, and the value is adjustable in increments of $\pm 1$ .
Print Speed	Determine the media speed during printing. The range is +2 ~ +6, and the value is adjustable in increments of $\pm 1$ ips.
Stop Position for Cutter	<p><b>Blank</b> Printer does not install cutter module.</p> <p><b>Head Position</b> Stop the paper forward on the head position.</p> <p><b>Cutter Position</b> Stop the paper forward on the cutter position.</p>
Stop Position for Dispenser	<p><b>Blank</b> Printer does not install dispenser module.</p> <p><b>Head Position</b> Stop the paper forward on the head position.</p> <p><b>Dispense Position</b> Stop the paper forward on the dispenser position.</p>
Tear Off Wait Time	Your printer moves the paper forward in a predefined time after printing, and pulls the paper back in a predefined length once the printing begins again.
Zero Slash	Display a zero with or without a slash through it.
Unit(Label)	<p><b>mm</b> Change the unit of <b>label</b> to millimeter.</p> <p><b>inch</b> Change the unit of <b>label</b> to inch.</p>
Width	Set the print width.
Height	Set the length of the label when using continuous media.
Unit (Position Adjustment)	<b>mm</b> Change the unit of <b>Position Adjustment</b> to millimeter.

Property Name	Description
	<b>Inch</b> Change the unit of <b>Position Adjustment</b> to inch. <b>dots</b> Change the unit of <b>Position Adjustment</b> to dots.
Horizontal Offset	Move the print position horizontally. The positive number is left, and the negative number is right.
Vertical Offset	Move the print position vertically. The positive number is forward, and the negative number is backward.
Continuous Offset	Adjust the continues offset at which the continuous label is cut.
Tear Off Offset	Adjust the rest position of the media after a label is printed, which changes the position at which the label is torn or cut.
Cutter/Dispenser Offset	Adjust the cutter/dispenser offset position at which the label is peel or cut.
Status	This is communication protocol for SBPL. <b>Status 3</b> is Enq response and <b>Status 4</b> is for the communication via driver.
STX Code	When you use non-standard code, you can set the code in this section.
ETX Code	When you use non-standard code, you can set the code in this section.
ESC Code	When you use non-standard code, you can set the code in this section.
ENQ Code	When you use non-standard code, you can set the code in this section.
CAN Code	When you use non-standard code, you can set the code in this section.
NULL Code	When you use non-standard code, you can set the code in this section.
Offline Code	When you use non-standard code, you can set the code in this section.

■ SDPL, SEPL, SIPL, SZPL and AUTO

**SDPL, SEPL, SIPL, SZPL and AUTO** provides settings grouped in the **Supply, Control, Action, Label and Position Adjustment** area.



Property Name	Description
Sensor Type	It is the media sensor you are using. It includes <b>I-MARK</b> , <b>GAP</b> and <b>None</b> . When you perform media calibration, the sensor is set to the one you select.
Ribbon Sensor	<b>Thermal Transfer</b> Your printer uses the ribbon sensor to detect the ribbon, it is mean <b>Thermal Transfer (TT)</b> . <b>Direct Thermal</b> Disable the ribbon sensor, it is mean <b>Direct Thermal (DT)</b> .
Feed Key	It defines the action of the <b>FEED</b> button. <b>Feed</b> Your printer feeds a blank label each time the button is pressed. <b>Reprint</b> Your printer reprints the last label each time the button is pressed.
Head Check (Power on)	<b>Enable</b> Your printer checks broken pins on the printhead automatically once your printer is turned on. <b>Disable</b> Disable the auto head check.
Auto Calibration	<b>ON (Power on)</b> Your printer automatically calibrates media using a media sensor once it restarts or is turned on. <b>ON (Head close)</b> Your printer automatically calibrates

Property Name	Description
	<p>media using a media sensor every time you close the print module when the printer is turned on.</p> <p><b>ON (Power on and Head close)</b> Your printer automatically calibrates media using a media sensor after power on and every time you close the print module when the printer is turned on.</p> <p><b>OFF</b> You need to manually calibrate media using a media sensor as you change the media, or your printer won't work properly.</p>
Reprint After Error	<p><b>Enable</b> Your printer when caused by the error condition. The label is reprinted as soon as the error condition is corrected.</p> <p><b>Disable</b> Disable the reprint after error.</p>
Print Darkness	Adjust the darkness relative to the current darkness setting. The range is 0 ~ +30, and the value is adjustable in increments of $\pm 1$ .
Print Speed	Determine the media speed during printing. The range is +2 ~ +6, and the value is adjustable in increments of $\pm 1$ ips.
Unit(Label)	<p><b>mm</b> Change the unit of <b>label</b> to millimeter.</p> <p><b>inch</b> Change the unit of <b>label</b> to inch.</p>
Width	Set the print width.
Height	Set the length of the label when using continuous media.
Unit (Position Adjustment)	<p><b>mm</b> Change the unit of <b>Position Adjustment</b> to millimeter.</p> <p><b>Inch</b> Change the unit of <b>Position Adjustment</b> to inch.</p> <p><b>dots</b> Change the unit of <b>Position Adjustment</b> to dots.</p>
Horizontal Offset	Move the print position horizontally. The positive number is left, and the negative number is right.
Vertical Offset	Move the print position vertically. The positive number is forward, and the negative number is backward.
Tear Off Offset	Adjust the rest position of the media after a label is printed, which changes the position at which the label is torn or cut.
Cutter Offset	Adjust the cutter offset position at which the label is peel or cut.

**mm/inch/dot conversion process in Position Adjustment is as follows;**

**1. Input to the form in Setting Tool**

Unit	Value Setting condition
mm	The value is adjustable in increments of ± 0.1 mm and rounded to the 1st decimal place.
inch	The value is adjustable in increments of ± 0.01 inch and rounded to the 2nd decimal place.
dot	The value is adjustable in increments of ± 1 dot and rounded to an integer place.

**2. Units Conversion process**

1) When sending the value to the printer

The setting value is transmitted as **dot** information to the printer.

Case	Conversion process	Calculation (Setting value = A)		Rounding method
Case 1	mm ⇒ dot	203dpi	$A / 25.4 \times 203$	Rounded down to an integer place
		300dpi	$A / 25.4 \times 300$	
Case 2	inch ⇒ dot	203dpi	$A \times 203$	
		300dpi	$A \times 300$	

2) When getting the value from the printer

The setting value is transmitted as **dot** information from the printer.

Case	Conversion process	Calculation (Getting value = B)		Rounding method
Case 3	dot ⇒ mm	203dpi	$B \times 25.4 / 203$	Rounded down to the 1st decimal place. e.g. 2.183 -> 2.1
		300dpi	$B \times 25.4 / 300$	
Case 4	dot ⇒ inch	203dpi	$B / 203$	Rounded down to the 2nd decimal place. e.g. 2.117 -> 2.11
		300dpi	$B / 300$	

"mm/inch ⇔ dot" conversion always has a calculation difference in converting units.

These are cases where the setting value entered in the Setting Tool may change slightly due to requirements of the conversion process.


e.g. In case of **3.2** mm setting:

$$3.2 / 25.4 \times 203 = 25.5 \Rightarrow \mathbf{25} \text{ dot (Sending value to the printer)}$$

$$\mathbf{25} \times 25.4 / 203 = 3.12 \Rightarrow \mathbf{3.1} \text{ mm (Getting value from the printer)}$$

## COM

The **COM** tab provides the settings of the RS-232C port. When you use COM as your port, make sure the settings in the **COM** tab are the same as the port settings, or your printer won't work properly.



Property Name	Description
Baud Rate	The rate of signals transmitted per second. The larger the number, the faster the data transmission.
Data Length	The length of the data transmitted. It can be set to <b>7</b> or <b>8</b> bits.
Parity	It can be set to <b>Odd</b> , <b>Even</b> or <b>None</b> . A parity bit is added to a string of data bits to check if the data is correct. <b>Odd</b> The total number of “ones” in the data plus the parity bit is an odd number. <b>Even</b> The total number of “ones” in the data plus parity bit is an even number. <b>None</b> No parity check is used.
Stop Bit	The stop bit is at the end of a string of data bits. It is used in asynchronous transmission to let the receiver know that the string of data bits being transmitted is end.
Flow Control	Flow control is used to control the data flow between the computer and your printer. <b>XON/XOFF (DC1/DC3)</b> It is software flow control that uses control characters to handle data transmission. When your printer is unable to process the data, the computer sends, it

---

sends an XOFF signal to tell the computer to stop sending data; once your printer is able to accept data, it sends an XON signal to notify the computer to resume sending data.

**RTS** It is hardware flow control that uses dedicated wires to handle data transmission. When the computer is ready to send data to your printer, it sends a Request to Send (RTS) signal to your printer. If your printer is able to accept the data, it sends a Clear to Send (CTS) signal to the computer. That is, the computer starts sending data when it sees CTS on; it stops sending when it sees CTS off.

**None** No control is used for the handshake.

## LAN

The **LAN** tab provides network settings, including **TCP/IP**, **Current TCP/IP**, **Protocol**, **Server** and **SNMP Trap**.


Property Name	Description
IP Address (TCP/IP)	The static IP address of your printer.
Subnet Mask (TCP/IP)	The manually specified subnet mask of your printer.
Gateway (TCP/IP)	The manually specified gateway of your printer.
IP Address (Current TCP/IP)	The current IP address of your printer.
Subnet Mask (Current TCP/IP)	The current subnet mask of your printer.
Gateway (Current TCP/IP)	The current gateway of your printer.
Socket	<b>Enable</b> The host communicates with your printer via the socket. <b>Disable</b> Disable the socket.
Port Number	The LAN port number of your printer.
SNMP	<b>Enable</b> The host gets or sets parameters registered as SNMP entities. <b>Disable</b> Disable SNMP.
DHCP	<b>Enable</b> The DHCP server assigns an IP address, the subnet mask and the gateway to your printer automatically. By default, it is enabled. <b>Disable</b> You need to specify an IP address, the subnet mask and the gateway to your printer

Property Name	Description
Host Name	manually. It is the name of a DHCP client. The host name allows up to 32 alphanumeric characters. You can leave it blank or type a name you want. By default, there is no host name.
Client ID	It is an arbitrary value sent to the DHCP server to reserve an IP address for your printer. <b>Client ID</b> allows up to 32 hexadecimal characters. If you leave it blank, your printer automatically assigns “FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF” as the client ID.
Trap 1	Trap is a message type of SNMP. When <b>Trap 1</b> is enabled and its IP address is set correctly, your printer alerts the computer of the specified IP address as your printer is experiencing problems.
Trap 2	Same as Trap 1.


## Set up LAN Connection

If you want to use the **LAN** port to transfer data, you need to set up the network connection in the **LAN** tab.


1. Connect your printer and computer to a network device (hub, switch or router) with Ethernet cables.
2. In the **Input/Output Port** list, click **USB** or **COM**.



3. In the **Navigation** pane, click **Parameter Setting** and click the **LAN** tab.



4. Do one of the following to configure your TCP/IP settings:
  - If you have a static IP address, fill the **IP Address**, **Subnet Mask** and **Gateway** box under **TCP/IP** according to your network settings and click **Send**.



- If you don't have a static IP address, make sure **DHCP** is enabled and click **Send**.

5. After your printer restarts, click **Get** to get the TCP/IP information of your printer. If you are using a static IP address, you'll get the same TCP/IP settings as it is in the previous step; if you are using DHCP, The DHCP server will automatically populate the **IP Address**, **Subnet Mask** and **Gateway** boxes under **Current TCP/IP**.


6. In the **Input/Output Port** list, click **LAN**, and click **Setting**.



7. In the **Setting LAN** dialog box, do one of the following to configure your IP address:

- If you are using a static IP address, in the **IP Address** box, enter the IP address under **TCP/IP** in the **LAN** tab, and then click **OK**.

- If you are using a dynamic IP address provided by DHCP, in the **IP Address** box, enter the IP address under **Current TCP/IP** in the **LAN** tab, and then click **OK**.



The screenshot shows a dialog box titled "Setting LAN" with a close button in the top right corner. It contains two input fields: "IP Address" with the value "192.168.7.140" and "Port" with a dropdown menu showing "9100". At the bottom, there are two buttons: "OK" and "Cancel".



---

**Note** When DHCP is enabled and your printer is idle for a long time, the IP address of your printer may change. Click **Get** to get the new IP address if you find the current IP address is not working.

---

## IPv6

The **IPv6** tab provides IPv6 settings, including **IPv6** and **Current IPv6**.

Property Name	Description
Mode	<p>It determines how you get the IPv6 address of your printer.</p> <p><b>MANUAL</b> Specify an IPv6 address manually.</p> <p><b>DHCPv6</b> An IPv6 address is assigned by a Dynamic Host Configuration Protocol for IPv6 (DHCPv6) server.</p> <p><b>AUTO</b> It uses a stateless address that doesn't require a DHCPv6 server to allocate an IP address. A host generates an IPv6 address from router advertisements and a MAC address. Stateless auto-configuration supports plug and play functionality, which allows the printer to generate an IPv6 address by itself once it connects to an IPv6 network.</p>
Address Type	<p>It is the IPv6 address type of your printer.</p> <p><b>NONE</b> The system won't use the address you specified to generate an IPv6 address. It sets 0000::0000 as the IPv6 address.</p> <p><b>NORMAL</b> It uses a 128-bit unicast address that you specified.</p> <p><b>EUI</b> It is 64-bit Extended Unique Identifier (EUI-64)</p>

Property Name	Description
	that generates the second half of a unicast IPv6 address (last 64 bits) from a MAC address. You can also specify the second half of the address by entering the interface ID. <b>ANY</b> It uses a 128-bit any cast address that you specify. The printer needs to remember that the current address is an any cast address, since its format is the same as a unicast address.
IP Address (IPv6)	The static IPv6 address of your printer.
Interface ID	Short for interface identifier. It is used to identify the network interface of a host. You can specify the interface ID here.
IP Address (Current IPv6)	The current IPv6 address of your printer.
Link-Local Address	It is used for communications on a local network. The address always starts with FE80.

## Set up IPv6 connection


Before you set up IPv6, make sure you have IPv6 connectivity.

- Do one of the following to configure your IPv6 settings:
  - If you have a static IPv6 address, in the **Mode** list, click **MANUAL**; in the **IP Address** box, enter your IPv6 address and click **Send**.


The screenshot shows the IPv6 configuration interface. At the top, there are tabs for 'General', 'COM', 'LAN', 'IPv6', 'WLAN', and 'Bluetooth'. Below the tabs are 'Send' and 'Get' buttons. The 'IPv6' section contains the following fields:

- Mode:** A dropdown menu currently showing 'MANUAL'.
- Address Type:** A dropdown menu currently showing 'NORMAL'.
- IP Address:** A text input field containing the address '2610:0008:6800:2f3b:02ab:00fe:fe9a:030a'.
- Interface ID:** A text input field containing '0000 : 0000 : 0000 : 0000'.

- If you don't have a static IPv6 address, in the **Mode** list, click **DHCPv6**; in the **Address Type** list, click **Normal** and click **Send**.



2. After your printer restarts, click **Get** to get its IPv6 information. If you are using a static IPv6 address, you'll get the same settings as it is in the previous step; if you are using DHCPv6, the DHCPv6 server will automatically populate the **IP Address** and **Link-Local Address** boxes under **Current IPv6**.




3. In the **Input/Output Port** list, click **LAN**, and click **Setting**.




4. In the **Setting LAN** dialog box, do one of the following to configure your IP address:

- If you are using a static IP address, in the **IP Address** box, enter the IP address under **IPv6** in the **IPv6** tab and click **OK**.




- If you are using a dynamic IP address provided by DHCPv6, in the **IP Address** box, enter the IP address under **Current IPv6** in the **IPv6** tab and click **OK**.



**Note** If your IPv6 address has consecutive zeros, you can use a double-colon to compress them. For example, if your address is 2607:f0d0:1002:0051:0000:0000:0000:0006, you can shorten it like this: 2607:f0d0:1002:0051::0006. Remember that the double-colon can appear only once in the address. The leading zeros in a section can also be removed, so the shortest version of your address can be written as 2607:f0d0:1002:51::6.

## WLAN

The **WLAN** tab provides wireless network settings, including **IPv4**, **Current IPv4**, **Authentication**, **Information**, **WEP**, **WPA**, **Initialization**, **Protocol**, **Current Protocol**, **Server** and **EAP**.



Property Name	Description
IP Address (IPv4)	The static IPv4 address of your printer.
Subnet Mask (IPv4)	The manually specified IPv4 subnet mask of your printer.
Gateway (IPv4)	The manually specified IPv4 gateway of your printer.
IP Address (Current IPv4)	The current IPv4 address of your printer.
Subnet Mask (Current IPv4)	The current IPv4 subnet mask of your printer.
Gateway (Current IPv4)	The current IPv4 gateway of your printer.
RSSI	Short for received signal strength indicator. It measures your Wireless LAN signal strength. The bigger the number, the stronger the signal.
Network Authentication	<p><b>Open</b> It allows any device to authenticate to an access point (AP) and gain access to a network, but only the device with the correct WEP key can receive encrypted data while the AP uses WEP encryption.</p> <p><b>WPA-Personal</b> WPA-Personal uses Pre-Shared Key (PSK) authentication, in which all users use the same password to access a network. WPA is designed to replace WEP. It uses RC4 encryption as WEP, but provides extra security through TKIP.</p> <p><b>WPA2-Personal</b> WPA2-Personal includes all features of WPA-Personal, but it uses AES encryption to enhance security.</p> <p><b>802.1X</b> 802.1X is an IEEE standard that provides EAP-based authentication methods for network access control. It enhances security by centralizing user identification, authentication and key management.</p> <p><b>WPA-Enterprise</b> WPA-Enterprise offers centralized control over a network. It requires an 802.1X authentication server (RADIUS server) to validate users. Each user needs to enter individual username and password to access a network. It uses TKIP and RC4</p>

Property Name	Description
	algorithm to encrypt data. <b>WPA2-Enterprise</b> WPA2-Enterprise includes all features of WPA-Enterprise, but it uses AES encryption to enhance security.
WEP	<b>ON</b> Turn on WEP encryption. <b>OFF</b> Turn off WEP encryption.
WEP Key Index	The default key of WEP. You can set four keys and choose one of them as the default.
WEP Input Type	The type of your WEP key. <b>ASCII</b> If your key is generated in ASCII, select this. ASCII includes the English alphabet, numbers and punctuation symbols. <b>HEX</b> If your key is generated in hexadecimal (HEX), select this. HEX includes the numbers 0 to 9 and the letters A to F.
WEP Key 1-4	You can store four WEP keys.
WPA Encryption	It shows encryption methods depending on your network authentication. <b>AUTO</b> It allows the access point to use either TKIP or AES encryption. <b>TKIP</b> It is available for <b>WPA-Personal</b> and <b>WPA-Enterprise</b> . TKIP stands for Temporal Key Integrity Protocol. It is part of 802.11i standard of Wireless LAN. It enhances the security of WEP. TKIP uses 128-bit encryption. It dynamically changes keys for each packet using a rekeying mechanism, providing a strong protection against attackers. <b>AES</b> It is available for <b>WPA2-Personal</b> and <b>WPA2-Enterprise</b> . AES stands for Advanced Encryption Standard. It uses a series of mathematical operations that repeatedly rearrange data to encrypt it. <b>Note</b> 802.11n can only use AES encryption.
WPA Pre-Shared Key	It is a key shared between two parties that use a secure channel for communication. Anyone who knows the key can access the

Property Name	Description
	network. The length can be 1-63 alphanumeric characters excluding double quotation marks (“). Pre-shared key authentication is for home or small offices.
Module Restore Default	It resets all values in the Wireless LAN module.
Network Type	It determines how you connect your printer to a network. <b>Infrastructure</b> If you connect through an access point, select this. <b>Ad hoc</b> if you connect through a device which has connected to a network, select this. In Ad hoc mode, you can only use <b>Open</b> authentication.
Region	The country or region.
Channel	The Wireless LAN channel. You need to use the same channel as other devices for communication. The available channel varies according to your region.
SSID	The service set identifier. It is the name of a wireless network.
Port Number	The wireless LAN port number of your printer.
Channel (Current)	The current Wireless LAN channel.
SSID (Current)	The current service set identifier.
DHCP	<b>Auto</b> It tries to get an IP address from a DHCP server first. If failed, it uses the specified one. <b>Enable</b> It keeps trying to get an IP address from a DHCP server until it succeeds. <b>Disable</b> It uses the specified IP address.
Host Name	It is the name of a DHCP client. The host name allows up to 32 alphanumeric characters. You can leave it blank or type a name you want. By default, there is no host name.
EAP Method	It is available for <b>802.1X, WPA-Enterprise</b> and

Property Name	Description
	<p><b>WPA2-Enterprise</b> authentication.</p> <p><b>EAP-LEAP</b> LEAP stands for Lightweight Extensible Authentication Protocol. It changes the WEP key for each session, preventing attackers retrieving data by cracking the key.</p> <p><b>EAP-TLS</b> TLS stands for Transport Layer Security. EAP-TLS requires both a client and a server to exchange digital certificates to authenticate each other. It uses Public Key Infrastructure (PKI) to protect communication. A server and a client need to obtain certificates from a certification authority (CA), and use these certificates to validate each other's identity.</p> <p><b>EAP-TTLS</b> TTLS stands for Tunneled Transport Layer Security. It has two stages. First, a server sends its certificate to a client after it received an authentication request. This certificate is used to create an encrypted tunnel (TLS tunnel) between the server and the client. Second, both sides exchange attribute-value pairs (AVP) through this tunnel.</p> <p><b>PEAP</b> Short for Protected Extensible Authentication Protocol. Similar to EAP-TTLS, it creates an encrypted tunnel between a server and a client in the first stage. After that, it starts the second EAP exchange through this tunnel.</p> <p><b>EAP-FAST</b> FAST stands for Flexible Authentication via Secure Tunneling. Similar to PEAP, it has two stages. First, it uses a Protected Access Credentials (PACs) to create an encrypted tunnel. Second, it authenticates the client to the server within the tunnel.</p>
EAP Username	The username for EAP authentication. It

Property Name	Description
EAP Password	accepts 1-63 alphanumeric characters. The password for EAP authentication. It accepts 1-32 alphanumeric characters.


## Set up WLAN connection

Before you set up a wireless LAN connection, make sure your computer has connected to a wireless network.

1. In the **Input/Output Port** list, click **USB** or **COM**.



2. In the **Navigation** pane, click **Parameter Setting** and click the **WLAN** tab.



- In the **SSID** box, enter the network name you've connected and do one of the following to enter your password:

SSID:	dlink
-------	-------

- If you're using **Open** and **WEP** is on, choose your WEP password type in the **WEP Input Type** list. Next, enter your WEP password in one of the **WEP Key** box, and select the key you want to use from the **WEP Key Index** list.

WEP	
WEP:	ON
WEP Key Index:	1
WEP Input Type:	ASCII
WEP Key1:	00000000
WEP Key2:	
WEP Key3:	
WEP Key4:	

- If you're using **WPA-Personal** or **WPA2 Personal**, enter your password in the **WPA Pre-Shared Key** box.

WPA	
WPA Encryption:	AUTO
WPA Pre-shared Key:	00000000

- If you're using **802.1X**, **WPA-Enterprise** or **WPA2 Enterprise**, choose your EAP authentication method in the **EAP Method** list and enter your username and password in **EAP User Name** and **EAP Password** boxes respectively. If you're using TTLS mode, you can choose the TTLS encryption method from the **TTLS Method** list.

**EAP**

EAP Method:

EAP User Name:

EAP Password:

4. Do one of the following to configure your IPv4 settings:
- If you have a static IP address, fill the **IP Address**, **Subnet Mask** and **Gateway** box under **IPv4** according to your network settings, make sure **DHCP** is disabled and click **Send**.

**IPv4**

IP Address:

Subnet Mask:

Gateway:

**Server**

DHCP:

Host Name:

- If you don't have a static IP address, make sure **DHCP** is enabled and click **Send**.

**Server**

DHCP:

Host Name:

5. After your printer restarts, click **Get** to get the IPv4 information of your printer. If you are using a static IP address, you'll get the same settings as it is in the previous step; if you are using DHCP, the DHCP server will automatically populate the **IP Address**, **Subnet Mask** and **Gateway** boxes under **Current IPv4**.

Current IPv4	
IP Address:	192 . 168 . 0 . 120
Subnet Mask:	255 . 255 . 255 . 0
Gateway:	192 . 168 . 0 . 1

6. In the **Input/Output Port** list, click **LAN**, and click **Setting**.



7. In the **Setting LAN** dialog box, do one of the following to configure your IP address:

- If you are using a static IP address, in the **IP Address** box, enter the IP address under **IPv4** in the **WLAN** tab and click **OK**.

A screenshot of the 'Setting LAN' dialog box. The 'IP Address' field contains '155.181.255.28' and the 'Port' dropdown is set to '9100'. 'OK' and 'Cancel' buttons are at the bottom.

- If you are using a dynamic IP address provided by DHCP, in the **IP Address** box, enter the IP address under **Current IPv4** in the **WLAN** tab and click **OK**.

A screenshot of the 'Setting LAN' dialog box. The 'IP Address' field contains '192.168.0.120' and the 'Port' dropdown is set to '9100'. 'OK' and 'Cancel' buttons are at the bottom.

## Bluetooth


The **Bluetooth** tab provides Bluetooth settings.

Property Name	Description
Pin Code	The Bluetooth PIN code of your printer. The new PIN code takes effect when you reconnect your printer to your computer.
Device Name	The Bluetooth device name of your printer. The new device name takes effect after you reconnect your printer to your computer.
BD Address	The Bluetooth MAC address of your printer.
Inquiry Control	It determines how your printer is detected by other Bluetooth devices. <b>Response is made at any time</b> Your printer is always detectable. <b>No response</b> Your printer is not detectable. <b>Response only within 60sec after a power on</b> Your printer is detectable in 60 seconds after it is turned on.

## Reset parameter setting


If you want to reset **Parameter Setting**, do this:

1. In **Parameter Setting**, right-click in the blank area in any tab.




2. In the shortcut menu, do one of the following to reset **Parameter Setting**:

- If you want to restore all of the settings to their default values, click **Restore to Default**.



- If you want to restore the settings of the current tab to their default values, click **Restore Display to Default**.



## Download

**Download** is used to download files to your printer. Tabs in **Download** are related to the emulation language you choose. Remember that you need to set up a network connection before you use the **LAN** port for the data transfer. For further details, see [Set up LAN connection](#), [Set up IPv6 connection](#) and [Set up WLAN connection](#).

## Firmware


The **Firmware** tab displays in all emulation modes. It is used to update firmware. For information about update firmware in SATO WS4 Printer Utility, see [Update firmware in SATO WS4 Printer Utility](#).

## General


The **General** tab displays in all emulation modes. It is used to send command files to your printer and perform tasks. Command files only run in their corresponding emulations. For example, SZPL command files only run in SZPL emulation.

To run commands on your printer:


1. Type your commands in any text editor, such as Notepad or WordPad.
2. Save your commands as text files (.txt).
3. In the **Input/Output Port** list, click the port you want to use.




4. Click **Download** in the **Navigation** pane.



5. Under the **General** tab, right-click in the blank area and click **Add**.




- In the **Open** dialog box, browse to the folder that contains command files, select them and click **Open**. The command files you select must correspond to the emulation language you use.



- In the list, select the file you want to use. You can only select one file at a time.

Filename	In Folder	Size
<b>File</b>		
<input type="checkbox"/> 100KB_graphic.prn	C:\Documents and Settings\Nion\Desktop\test command	111885 B
<input checked="" type="checkbox"/> 203DirectA03ips.dat	C:\Documents and Settings\Nion\Desktop\test command	3130 B
<input type="checkbox"/> get everything.txt	C:\Documents and Settings\Nion\Desktop\test command	73 B
<input type="checkbox"/> kic.txt	C:\Documents and Settings\Nion\Desktop\test command	19 B
<input type="checkbox"/> selftest.bin	C:\Documents and Settings\Nion\Desktop\test command	21 B


8. Click **Send** to run the command on your printer.



**Note** If you send a command file and your printer doesn't respond, it is possible that the emulation language is not set correctly. Click **Sync** to get the current setting of **Printer Emulation**.

## Tool

**Tool** is used to send specific commands to your printer. It has the **Single Command** tab, which provides three commands.



- **Reboot Printer** Restart your printer.
- **Reset to Default Setting** Reload factory settings.
- **Test Print** Run a self-test to print a configuration label.
- **Change Emulation** Change the emulation language for your printer.
- **Media Calibration** Change the media sensor for your printer.
- **Ribbon Calibration** It calibrates the ribbon so that your print start position will be more accurate.
  - **RESET** Turn off **Ribbon Calibration**.

- **ON** Turn on **Ribbon Calibration**. Enter the height of your label in the scale box. For example, if the height of your label is 100 mm, enter 100 in the box.

# 5 Update Firmware

Firmware is the code stored permanently in hardware. It instructs your printer to do its tasks. Benefits of updating firmware include new features, enhanced functionality and improved performance.



**Caution** Do not open the print module, disconnect your printer from the computer or cut your printer power during the firmware update.

## 5.1 Update Firmware in SATO WS4 Printer

### Utility

This section describes how to update printer firmware in SATO WS4 Printer Utility.

#### 5.1.1 Update via the USB or COM Port


1. Connect your printer and the computer with a USB or a serial cable.
2. Make sure the print module is closed.
3. Turn on your printer, and start SATO WS4 Printer Utility.
4. In the **Input/Output Port** list, click **USB** or **COM**, and do one of the following:
  - If you are using the **USB** port, the **Port Name** and **Port Information** automatically shows the USB information. You don't need to do anything.




- If you are using the **COM** port, click **Setting**, and change the settings as you want. For example, you can change **Baud Rate** to a higher value to speed up the data transmission. Make sure the port settings are the same as those in the **COM** tab in **Parameter Setting**, or your printer won't work properly.




5. In the **Navigation** pane, click **Download** and click the **Firmware** tab.




6. Right-click in the blank area and click **Add**.



7. In the **Open** dialog box, browse to the folder that contains the firmware files. Select all of them and click **Open**.




8. If you want to update specific files, select the check boxes of those files; if you want to update all of the firmware files, right-click in the blank area in the list and click **Select All**.




9. Click **Send** to send the firmware files to your printer. During the transmission, LED 1 blinks green. In the **Download Firmware** dialog box, the message shows the file your printer is downloading, and the progress bar indicates the progress of downloading.



- When the data transmission is complete, your printer starts to update its firmware. During the update, LED 2 turns to red and orange alternatively, while LED 1 turns to solid green. In the **Download Firmware** dialog box, the message shows that your printer is updating the firmware.




- Printer will restart automatically after the message "Firmware Update, Succeed" appears.



- When the update is complete, the message "Firmware Update Complete" appears. Click **Close** to close the dialog box, or click **Save Log** to save the

firmware update log.



**Note** Sometimes you'll find LED 2 keeps turning to red and orange alternatively after the message "Done" appears. It means your printer is updating the other copy of firmware. There are two copies of firmware stored in your printer: master and backup. They are used to restore each other in case the firmware is lost or corrupted. By default, the master is the primary copy. Your printer uses the backup if the master doesn't work.

## 5.1.2 Update via the LAN Port

Before you update the firmware via the **LAN** port, you need to set up a network connection. For details, see [Set up LAN connection](#), [Set up IPv6 connection](#) and [Set up WLAN connection](#).

1. Make sure the print module is closed.
2. Turn on your printer, and start SATO WS4 Printer Utility.
3. In the **Input/Output Port** list, click **LAN**, and do one of the following:
  - If you are using the **LAN** port, the **Port Name** and **Port Information** will show the LAN settings after you set up a network connection.

LAN




IPv6




WLAN




4. In the **Navigation** pane, click **Download**, and click the **Firmware** tab.




5. Right-click in the blank area and click **Add**.




- In the **Open** dialog box, browse to the folder that contains the firmware files. Select all of them and click **Open**.




- If you want to update specific files, select the check boxes of those files; if you want to update all of the firmware files, right-click in the blank area in the list and click **Select All**.




8. Click **Send** to send the firmware files to your printer. During the transmission, LED 1 blinks green. In the **Download Firmware** dialog box, the message shows the file your printer is downloading and the progress bar indicates the progress of downloading.




9. When the data transmission is complete, your printer starts to update its firmware. During the update, LED 2 turns to red and orange alternatively, while LED 1 turns to solid green. In the **Download Firmware** dialog box, the message shows that your printer is updating the firmware.



10. Printer will restart automatically after the message “Firmware Update, Succeed” appears.



11. When the update is complete, the message “Firmware Update Complete” appears. At the same time, your printer restarts itself. Click **Close** to close the dialog box or click **Save Log** to save the firmware update log.



## 5.2 Update Firmware via the USB Host

The USB host is a USB type A port for a USB flash drive, which can be used to quickly update the firmware.

1. Create a folder named “Firmware” in your USB flash drive, and copy the firmware files to it. The file “WS4-master.abin” needs to be in the folder.
2. Make sure the print module is closed and turn off your printer.
3. Turn ON the printer power (or reboot the printer) after insert your USB flash drive to the printer. The printer starts to transmit the firmware when LED bling one and another.

**Note** You cannot transmit firmware even if insert your USB flash drive to the printer after turn ON the printer power (or reboot the printer).

4. When LED 1 and LED 2 are all green light, turn off the printer power, then remove USB flash driver.
5. Turn on the printer power. During the update, LED 2 blinks green a few times, and turns to red and orange alternatively. When the update is complete, LED 2 goes out.



**Caution** Do not remove the USB flash drive during the transmission.

---

## 5.3 Update Firmware in Atmel Mode

Service Engineer only

Typically, firmware can be updated in SATO WS4 Printer Utility without problems, but there are rare cases SATO WS4 Printer Utility cannot handle. If any unexpected conditions keep you from update firmware in SATO WS4 Printer Utility, you need to update it in Atmel mode.

### Step 1. Enter Atmel Mode

This part describes how to enter Atmel mode.

1. Turn off your printer.
2. Turn over your printer.
3. Loosen and remove four screws from the base.
4. Lift the base and unplug all the cables.
5. Locate the DIP switch on the main board. Set Switch 1 and 2 to the **OFF** position (down).




### Step 2. Update Your Firmware


This part describes how to update your firmware in Atmel mode.

1. Plug all the cables back into the main board.
2. Turn on your printer. Both LEDs won't glow. This is normal.


3. Start SATO WS4 Printer Utility. In the **Navigation** pane, click **Download** and click the **Firmware** tab.



4. Right-click in the blank area and click **Add**.




- In the **Open** dialog box, browse to the folder that contains WS4 firmware files. Select all of them and click **Open**.




- Right-click in the blank area in the list and click **Select All** to select all of the check boxes.

**Note:** If you want to execute a firmware file without saving it into the flash memory, select the **Download to memory and execute** check box and click **Send**.




- Click **Send** to send the firmware files to your printer. When the update is complete, the message “Done” appears. Click **Close** to close the dialog box or click **Save Log** to save the firmware update log.



### Step 3. Exit Atmel Mode

This part describes how to exit Atmel mode.

- Turn off your printer.
- Set **DIP Switch** 1 and 2 to the **ON** position (up). If it's inconvenient to set **DIP Switch** while cables are connected, unplug all the cables to do this.



- Reinstall the base and the secure it with four screws.
- Turn over your printer.
- Turn on your printer.

# 6 Troubleshooting

This chapter provides the information about accessories issues, internal errors and their possible solutions.

## 6.1 Cutter and Dispenser Issues

Issue	Solution
The cutter is experiencing issues.	<ul style="list-style-type: none"> <li>■ If there is a paper jam, clear it.</li> <li>■ The cutter has become loose. Fix the cutter in position and tighten it.</li> <li>■ The cutter blade is not sharp anymore. <u>Replace your cutter with a new one.</u></li> </ul>
The dispenser is experiencing issues.	<ul style="list-style-type: none"> <li>■ If there is a paper jam, clear it.</li> <li>■ The dispenser has become loose. Fix the dispenser in position and tighten it.</li> <li>■ Make sure the liner is correctly threaded into the dispenser slot.</li> </ul>

## 6.2 Internal Errors


Error	Solution
Communication error (RS-232C).	<ul style="list-style-type: none"> <li>■ Check the serial cable to see if it is working okay.</li> <li>■ Make sure the serial cable is connected properly and the computer is turned on.</li> <li>■ In <b>Printer Utility 2013</b>, the settings of the <b>COM</b> port need to be the same as those in the <b>COM</b> tab in <b>Parameter</b>.</li> <li>■ The serial cable might not be wired correctly or might be damaged. Try to rewire it or get a new one.</li> </ul>
Flash ROM on the CPU board error or USB memory error.	<ul style="list-style-type: none"> <li>■ Check your USB flash drive and see if it works properly.</li> </ul>
An erase error has occurred when formatting the USB memory.	<ul style="list-style-type: none"> <li>■ Make sure your USB flash drive is tightly plugged.</li> <li>■ The flash ROM or USB drive is damaged. Replace it.</li> </ul>
Unable to save files due to insufficient USB memory.	<ul style="list-style-type: none"> <li>■ Delete the files on your USB drive to free some space, or replace your USB drive with an empty one.</li> </ul>
Command error.	<ul style="list-style-type: none"> <li>■ Press the <b>FEED</b> button.</li> <li>▪ Turn off the printer, and turn it on again.</li> </ul>
An EEPROM for backup cannot be read or written properly.	<ul style="list-style-type: none"> <li>■ It is possible that the EEPROM is damaged. Replace it or the main board.</li> </ul>
A command has been fetched from an odd address.	
Word data has been accessed from a place other than the boundary of the word data.	
Long word data has been accessed from a place other than the boundary of the long word data.	<ul style="list-style-type: none"> <li>■ Check your commands and make sure they are correct.</li> </ul>
An undefined command in a place other than the delay slot has been decoded.	

Error	Solution
<p>An undefined command in the delay slot has been decoded.</p> <p>A command which rewrites the data in the delay slot has been decoded.</p>	

# 7 Network

This chapter provides the information about the printer networking.

## 7.1 Network Architecture



As the figure shows, the network architecture includes several layers, and each layer corresponds to the layer in the Open Systems Interconnection (OSI) model.

The print engine is on the application layer. It is a set of programs that handle most jobs for the printer, such as receiving data, analyzing data, drawing images, printing images and returning status. It communicates with TCP via the socket.

The socket is on the session layer. It is an application program interface (API) that opens, receives, sends and closes TCP sessions between the printer and network nodes to exchange data.

Transmission Control Protocol (TCP) and Internet Protocol (IP) are on the transport and the network layer, respectively. These two layers work closely together. The transport layer secures end-to-end data transfer by establishing a reliable connection that includes features such as packet resend control, packet order control, flow control and error checking. TCP is the protocol commonly used in

transport layer.

IP is the commonly used protocol in the network layer. It defines an address system and provides end-to-end communication for data transmission. The packet is delivered based on the IP address in the IP header, which is attached to the packet. However, the packet may be lost, corrupted or out-of-order when it travels across the network, because IP doesn't ensure the delivery. TCP can prevent most of these things happen.


The data link is on the data link layer. Its task is to create and manage a reliable data transmission between two adjacent nodes in a network via MAC addresses. It divides the data from the network layer into bits, encodes these bits into frames prior to transmission, and decodes them at the destination. The data link also provides the error control and flow control. The error control uses a frame check sequence (FCS) to ensure that the delivered frames are intact, and the flow control ensures that the fast sender doesn't overwhelm the slow receiver with data.

This architecture allows up to five computers to connect to a printer via the same port. When you turn on the printer, it opens the maximum number of ports and is waiting for a session request. Once the printer receives a request, it establishes a session and set it as "connected." If all of the sessions are occupied, no more connection is allowed. In this case, the printer returns the RST signal to the computer that made a request via the TCP protocol. When the printer finishes its communication with the computer, it releases the session to get ready for a new connection.

Data processing is determined by the connection priority. When your printer connects to multiple computers, it only processes the data from the oldest session (the first connected computer). The connection priority changes when there is a disconnection. Other computer needs to wait until its session becomes the oldest.

## 7.2 Ethernet Status Indicators

LED	Indicator	Status	Description	Note
Green	Speed	ON	100 Mbps	When both LEDs are off, there is no Ethernet connection.
		OFF	10 Mbps	
Amber	Link	ON	Link Up	
	Activity	OFF	Link Down	
		Blink	Activity	



Green LED

Amber LED

# 8 Specifications

This chapter provides specifications of the printer. Specifications are subject to change without notice.

## 8.1 Printer

Model	WS408TT	WS412TT
<b>Print method</b>	Direct Thermal and Thermal Transfer	
<b>Resolution</b>	203 dpi (8 dots/mm)	300 dpi (12 dots/mm)
<b>Media Alignment</b>	Center Alignment	
<b>Operation Mode</b>	Standard: Continuous, Tear-off Optional: Full Cutter, Dispenser	
<b>Sensor</b>	Media Sensor	Gap Sensor (Transmissive, Fixed) Offset: 6.27mm - Factory Default Sensor
		I-Mark Sensor (Reflective, Movable)
		Head Open Switch
<b>Print Speed</b>	2, 3, 4, 5, 6 inches/sec (50.8, 76.2, 101.6, 127, 152.4 mm/sec) 2 & 3 ips for peel off mode	2, 3, 4 inches/sec (50.8, 76.2, 101.6 mm/sec) 2 & 3 ips for peel off mode
	Do not set Print Speed to 4 ips or higher speed, when the dispenser module is installed and the dispenser cover is open.	
<b>Print Darkness</b>	Darkness level – SBPL: 1~5 Default – SBPL: 2	
<b>Max Printable Area</b>	Length 999 mm x Width 104 mm	Length 999 mm x Width 104 mm
<b>Non-Printable Area</b>	Pitch Direction - Top: 1.5 mm, Bottom: 1.5 mm (excluding liner) Width Direction - Left: 1.5 mm, Right: 1.5 mm (excluding liner)	
<b>Print Ratio</b>	Average print ratio within 15 % or less (whole print layout area) Full width with 1mm pitch is required	
<b>Interface</b>	STD Model: USB (Type A and Type B), Ethernet, RS232C LAN Model: USB (Type A and Type B), Ethernet	



Model	WS408TT	WS412TT
<b>Accessories</b>	Dispenser, Full Cutter, External Unwinder	
<b>CPU</b>	32bit RISC	
<b>On-Board Memory</b>	Standard Memory (Flash ROM): 16 MB User Memory: 2 MB Standard Memory (SDRAM): 32 MB	
<b>External Memory</b>	USB: Max 16 GB	
<b>Panel</b>	2 LED, 1 Button	
<b>LED</b>	1 <sup>st</sup> LED: Red and Green (Various Combinations: Orange) 2 <sup>nd</sup> LED: Red and Green (Various Combinations: Orange)	
<b>Font</b>	Bitmap: XS, XU, XM, XB, XL, OCR-A, OCR-B Scalable: CG Times, CG Triumvirate	

## 8.2 Media and Ribbon

Properties	Description
<b>Media Size</b>	<p><b>Continuous Mode</b></p> <p>Length (TT): 8 mm ~ 996 mm (including liner 11 ~ 999 mm)</p> <p>Length (DT): 8 mm ~ 996 mm (including liner 11 ~ 999 mm)</p> <p>Width: 22.4 mm ~ 115 mm (including liner 25.4 ~ 118 mm)</p> <p><b>Tear-Off Mode</b></p> <p>Length (TT): 8 mm ~ 996 mm (including liner 11 ~ 999 mm)</p> <p>Length (DT): 30 mm ~ 996 mm (including liner 33mm~999m)</p> <p>Width: 22.4 mm ~ 115 mm (including liner 25.4 ~ 118 mm)</p> <p><b>Dispenser Mode</b></p> <p>Length (TT): 23.4 mm ~ 150.4 mm (including liner 26.4 ~ 152.4 mm)</p> <p>Length (DT): 35 mm ~ 150.4 mm (including liner 38mm~153.4mm)</p> <p>Width: 22.4 mm ~ 115 mm (including liner 25.4 ~ 118 mm)</p> <p><b>Cutter Mode</b></p> <p>Length (TT): 19.4 mm ~ 993 mm (including liner 22.4 ~ 996 mm)</p> <p>Length (DT): 35 mm ~ 993 mm (including liner 38mm~996mm)</p> <p>Width: 22.4 mm ~ 115 mm (including liner 25.4 ~ 118 mm)</p> <p>Media Thickness: 0.06~0.19mm</p> <p>Max Roll Diameter Size: 127 mm (5 inches)</p> <p>Max Roll Diameter Size for External Unwinder: 216 mm (8.5 inches)</p>
<b>Media Type</b>	<p>Thermal Transfer Label</p> <p>Thermal Transfer Tag</p> <p>Direct Thermal Label</p> <p>Direct Thermal Tag</p> <p>Roll Paper (Face-Out/Face-In)</p> <p>Fanfold Paper</p>
<b>Ribbon Size</b>	<p>Length: 100 m (φ Core Size: 0.5 inch), Max 300 m (φ Core Size: 1 inch)</p> <p>Width: 40 mm ~ 110 mm</p>
<b>Ribbon Type</b>	<p>Wax, Wax-Resin, Resin</p> <p>Coated Side In or Coated Side Out</p>



## 8.3 Bar code

Programming Language	SZPL\SDPL\SEPL
<b>One Dimensional Bar Code</b>	UPC-A
	UPC-E
	JAN/EAN
	CODE39
	CODE93
	CODE128
	GS1-128 (UCC/EAN128)
	CODABAR (NW-7)
	ITF
	Industrial 2of5
	MSI
	UPC add-on code
	POSTNET
	GS1 DataBar
	Omnidirectional
	GS1 DataBar Truncated
	GS1 DataBar Stacked
	GS1 DataBar Stacked
	Omnidirectional
	GS1 DataBar Limited
	GS1 DataBar Expanded
GS1 DataBar Expanded	
Stacked	
<b>Two-Dimensional Bar Code</b>	QR Code
	PDF417 (including MicroPDF)
	DataMatrix (ECC200)
	GS1 DataMatrix
	MaxiCode
<b>Composite Symbol</b>	EAN-13 Composite (CC-A/CC-B)
	EAN-8 Composite (CC-A/CC-B)
	UPC-A Composite

Programming Language	SZPL\SDPL\SEPL
	(CC-A/CC-B)
	UPC-E Composite
	(CC-A/CC-B)
	GS1 DataBar Composite
	(CC-A/CC-B)
	GS1 DataBar Truncated Composite (CC-A/CC-B)
	GS1 DataBar Stacked Composite (CC-A/CC-B)
	GS1 DataBar Expanded Stacked Composite (CC-A/CC-B)
	GS1 DataBar Expanded Composite (CC-A/CC-B)
	GS1 DataBar Stacked Omnidirectional Composite (CC-A/CC-B)
	GS1 DataBar Limited Composite (CC-A/CC-B)
	GS1-128 Composite (CC-A/CC-B/CC-C)

## 8.4 Wireless LAN

Properties		Wireless LAN I/F		
<b>Hardware</b>	Protocol	IEEE 802.11 b/g/n		
	Enabled Device	WS4 Series		
	Operating Temperature	-4 degF (-20 degC) ~ 185 degF (+85 degC)		
	Destination	USA	Europe	
	Frequency (Center Channel)	2412 ~ 2462 MHz	2412 ~ 2472 MHz	
	Channel	1 ~ 11 ch	1 ~ 13 ch	
	Spacing	5 MHz		
	Transmission Speed/Modulation	IEEE 802.11b	Transmission Method	Conforming to IEEE 802.11b DSSS method
			Channel	Depending on the country
			Data Transmission Speed/Modulation	11/5.5 Mbps: CCK 2 Mbps: DQPSK 1 Mbps: DBPSK
		IEEE 802.11g	Transmission Method	Conforming to IEEE 802.11g OFDM method DSSS method
			Channel	Depending on the country
			Data Transmission Speed/Modulation	54/48 Mbps: 64 QAM 36/24 Mbps: 16 QAM 18/12 Mbps: QPSK 9/6 Mbps: BPSK
		IEEE 802.11n	Transmission Method	Conforming to IEEE802.11n OFDM method
		Channel	US)1-11ch (JP/DE)1-13ch	
		Data Transmission Speed/Modulation	20MHz: 6.5M / 7.2M / 13M / 14.4M / 19.5M / 21.7M / 26M /28.9M /	



Properties	Wireless LAN I/F
	72.2M(Auto-sensing)
Antenna	External antenna
Aerial power	802.11b Max +15 dBm
	802.11g Max +17 dBm
	802.11n Max +17 dBm
<b>Software</b>	Connection Mode Infrastructure, Adhoc
Default IP Address	192.168.1.1
Default Subnet Mask	255.255.255.0
Default ESSID	SATO_PRINTER
Security	IEEE 802.11i
Cryptograph hy	WEP 128 bit, TKIP (WPA), AES (WPA2)
Authorizati on	Shared Key, Open System, PSK, PEAP, TLS, TTLS, LEAP, EAP-FAST
Protocol (*)	TCP/IP, Socket, DHCP
Wireless LAN Parameter and Status Monitor	Parameter: Command (Printer Utility)

## 8.5 Bluetooth

Properties	Bluetooth I/F
Standard	Bluetooth 2.1 + EDR or later
Enable Device	WS Series
Operating Temperature	41°F (5°C) ~ 104°F (40°C)
Storage Temperature	-4°F (-20°C) ~ 140°F (60°C)
Operating Humidity	25 ~ 85 % Non-condensing R.H
Storage Humidity	10 ~ 90 % Non-condensing R.H
Connection Form	Only one-to-one connection is supported.
Support Profile	Serial Port Profile (SPP) PIN code is supported.
Class of Radio Transmission	CLASS 2
Transmission Method	Bi-directional (Half-duplex)
Flow Control	Credit based flow control
Operating Mode	Slave Mode
Transmission Distance	3 m (360 degrees)
SR Mode in Page/Inquiry Scanning	R1 Scan Interval 1.28 sec. Scan Window 22.5 msec.
RF Frequency Range	2402 ~ 2480 MHz
Nominal Output Power	+4 dBm (2.51 mW) MAX

## 8.6 Ethernet

Properties	Description
<b>Port</b>	RJ-45
<b>Speed</b>	10Base-T/100Base-T (Auto Detecting)
<b>Protocol</b>	ARP, IP, ICMP, UDP, TCP, HTTP, DHCP, Socket, LPR, IPv4, SNMPv2
<b>Mode</b>	TCP Server/Client, UDP Client
<b>Technology</b>	HP Auto-MDIX, Auto-Negotiation

## 8.7 Electrical and operating environment

Properties	Range
<b>Power Supply</b>	Voltage: AC 100 V ~ 240 V $\pm$ 10 % (full range) Frequency: 50 Hz ~ 60 Hz $\pm$ 5 %
<b>Power Consumption</b>	90 W
<b>Temperature</b>	Operating: 5 °C ~ 40 °C Storage: -20 °C ~ 60 °C
<b>Humidity</b>	Operating: 25 %RH ~ 85 %RH (non-condensing) Storage: 10 %RH ~ 90 %RH (non-condensing)

## 8.8 Physical dimension


Dimension	Size and Weight
<b>Size</b>	W 220.6 $\pm$ 0.5mm x D 278.5 $\pm$ 0.5mm x H 187.5 $\pm$ 0.5mm
<b>Weight</b>	2.48 kg $\pm$ 3% (excluding media and options) or less

## 8.9 Interfaces

This section provides information about IO port specifications for the printer.

### 8.9.1 USB


The printer has two USB ports: type A and type B. Typically, type A is found on computers and hubs; type B is found on devices and hubs. The figure below shows their pinouts.



Pin	Signal	Description
1	VBUS	+5V
2	D-	Differential data signaling pair -
3	D+	Differential data signaling pair +
4	Ground	Ground

## 8.9.2 Ethernet


The Ethernet uses RJ-45 cable, which is 8P8C (8-Position 8-Contact). The figure below shows its pinout.



Pin	Signal
1	Transmit+
2	Transmit-
3	Receive+
4	Reserved
5	Reserved
6	Receive-
7	Reserved
8	Reserved

### 8.9.3 RS-232C

The RS-232C on the printer is DB9 female. It transmits data bit by bit in asynchronous start-stop mode. The figure below shows its pinout.



Pin	Signal	Description
1	+5V	Provide 5V Power
2	RxD	Receive
3	TxD	Transmit
4	NC	No Connection
5	GND	Ground
6	Hi	Pull High
7	RTS NC	Request to Send
8	CTS	Clear to Send
9	Hi	Pull High

Speed: 2400, 4800, 9600, 19200, 38400, 57600, 115200 Bauds

Parity: Odd, Even or None

Data Bits: 7 or 8 Bits

Stop Bits: 1 or 2 Bits

Flow Control: XON/XOFF or RTS


Default Parameters: 9600 Bauds, No Parity, 8 Data Bits, 1 Stop Bit, XON/XOFF

Host (DB9)			Printer (DB9)		
Signal	Description	Pin	Pin	Description	Signal
CD	Carrier Detect	1	1	Provide 5V Power	+5V
RxD	Receive	2	2	Receive	RxD
TxD	Transmit	3	3	Transmit	TxD
DTR	Data Terminal Ready	4	4	No Connection	NC
GND	Ground	5	5	Ground	GND
DSR	Data Set Ready	6	6	Pull High	Hi
RTS	Request to Send	7	7	Request to Send	RTS
CTS	Clear to Send	8	8	Clear to Send	CTS
CI		9	9	Pull High	Hi

# 9 Technical Drawings

This chapter provides technical drawings of the printer.

## 9.1 Main Board Diagram



### Main Board

A printed circuit board assembly (PCBA) consists of a microcontroller, flash memory, SDRAM and more.

### Panel

A two-layer PCBA consists of one button and two LEDs.

### Ribbon Sensor

A two-layer PCBA consists of a reflective type sensor, which is designed for ribbon detection.

**Media Sensor**

A two-layer PCBA consists of a reflective and a transmissive sensor, which is designed for media detection.

**Thermal Printhead (TPH)**

It consists of a line of tiny resistors that is electronically controlled to produce heat for printing. For thermal transfer printing, a TPH heats up and melts the ink from a ribbon to transfer it onto the thermal paper. The ink permanently adheres to the paper after it cools. For direct thermal printing, a TPH directly heats up an area of the thermal paper to produce an image.


**Stepper Motor**

A stepper motor rotates certain degrees in each step-in response to an electronic pulse.

**Cutter or Dispenser (Optional)**

A cutter is a guillotine cutter which automatically cuts the printed label. There are two cutting types: full and partial. A dispenser automatically removes the liner from a printed label. The sensor on the dispenser detects if the peeled label is taken away.

## 9.2 System Diagram



**Microcontroller (U11)**

The microcontroller (MCU) is AT91SAM9260. The MCU is like a microcomputer which integrates CPU, memory, I/O ports, timers and other components. The CPU it uses is ARM926-based processor.

**Flash memory (U18)**

The flash memory stores firmware, graphics, label formats and soft fonts.

**SDRAM (U17)**

SDRAM is volatile memory, typically storing working buffers and parameters. After the power is turned off, all of the data is gone.

**RS-232 Buffer (U14)**

Convert the serial port signal to/from microcontroller to RS-232 voltage level.

**Keypad LED Matrix**

It is an interface for users to interact with the printer. It has a **FEED** button and two LEDs.

**Power (U13, U15, D19)**

A regulator converts 24V DC to 5V DC as the VCC source for most of components on main board. LDOs are 5V to 3.3V for I/O, 3.3V to 1.8V for CPU core.

**Motor Driver (U2)**

The motor driver is BD63877. It acts as an amplifier, which takes low-current signals and generates high-current signals. Since the motor typically requires voltages or currents that exceed what the circuitry can provide, the motor driver is capable of providing higher voltages or currents for the motor.


**Ethernet PHY (U9)**

It is used to send and receive Ethernet frames. It complies with the IEEE 802.3 specifications for 10BASE-T and 100BASE-TX.

**TPH Driver (U4)**

The TPH driver IC is used to switch TPH heaters on and off.

### 9.3 Wiring Diagram



# Appendix A: DIP Switch

DIP Switch	Description	Description	Default
1	Switch between the firmware mode and Atmel mode.	ON: Firmware mode. It boots the printer from the flash memory. OFF: Atmel mode. It boots the printer from CPU ROM. <b>Important</b> In Atmel mode, DIP 2 (watchdog) must be set to OFF.	ON
2	Enable or disable the watchdog.	ON: Enable watchdog OFF: Disable watchdog	ON
3	Reserved.	N/A	OFF
4	Reserved.	N/A	OFF
5	Reserved.	N/A	OFF
6	Reserved.	N/A	OFF
7	Select the printer type. It needs to be used with DIP 8.	DIP 7 <ON>, DIP 8 <ON> Printer Type: For developers to debug DIP 7 <ON>, DIP 8 <OFF> Printer Type: DT Reserve DIP 7 <OFF>, DIP 8 <ON> Printer Type: DT global DIP 7 <OFF>, DIP 8	Depending on the printer type
8	Select the printer type. It needs to be used with DIP 7.	<OFF> Printer Type: TT global	Depending on the printer type